

HIGH EAVE (SCULPTURED)

EH8000-HIGH EAVE




EH8100-HIGH EAVE (SCULPTURED) WITH EAVE STRUT

EH8110-HIGH EAVE (SCULPTURED) WITH HIGH EAVE GIRT

EH8200-HIGH EAVE CORNER

EH8000 - HIGH EAVE

[Download the DWG file by clicking here.](#)



EH8000

Detailer Notes:


1) N/A

EH8100 - HIGH EAVE (SCULPTURED) W/ EAVE STRUT

[Download the DWG file by clicking here.](#)


HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



| ROOF PANEL THICKNESS | HIGH EAVE TRIM |
|----------------------|----------------|
| 2" / 2.5" / 3" | F3340 |
| 4" / 5" | F3341 |
| 6" | F3342 |

PART MARKS MAY CONTAIN A "-" NUMBER INDICATING ROOF SLOPE



HIGH EAVE STRUT

INSULATED METAL PANEL ROOF AT HIGH EAVE

EH8100

Detailer Notes:



1) N/A

EH8110 - HIGH EAVE (SCULPTURED) W/ HIGH EAVE GIRT

[Download the DWG file by clicking here.](#)

HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



HIGH EAVE GIRT

INSULATED METAL PANEL ROOF AT HIGH EAVE


EH8110

Detailer Notes:


1) N/A

EH8200 - HIGH EAVE CORNER DETAIL


[Download the DWG file by clicking here.](#)



HIGH EAVE CLOSURE SECTION



RIDGE CLOSURE TERMINATION DETAIL



HIGH EAVE CORNER DETAIL

EH8200

Detailer Notes:

- 1) N/A