
EAVE EXTENSIONS AND CANOPIES

SOFFIT DETAILS

- DO0005 - SOFFIT PANEL ERECTION DETAIL
- DO0006 - URBAN SERIES SOFFIT PANEL ERECTION DETAIL
- DO0007 - FLAT SL PANEL ATTACHMENT DETAIL
- DO0510 - CANOPY SOFFIT TERM. AT BEAM
- DO0610 - SOFFIT PANEL ENDLAP
- DO0615 - SOFFIT PANEL - RIDGE 1:12
- DO0616 - SOFFIT PANEL - RIDGE > 1:12
- DO0617 - SOFFIT PANEL - METRO RIDGE TERM.
- DO0618 - SOFFIT PANEL - SKYLINE RIDGE TERM.
- DO0619 - SOFFIT PANEL - FLAT SL PANEL RIDGE TERM.

LOW EAVE DETAILS

- DO0700 - LOW EAVE EXT. / CANOPY WITH SOFFIT
- DO0701 - LOW EAVE EXT. / CANOPY WITHOUT SOFFIT
- DO0710 - INTERIOR LOW EAVE AT BUILDING WITH SOFFIT
- DO0711 - INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT
- DO0712 - INTERIOR LOW EAVE AT BUILDING WITH SOFFIT (EAVE PURLIN)
- DO0713 - INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT (EAVE PURLIN)
- DO0720 - RAKE EXT. TERM. AT LOW EAVE WITH SOFFIT
- DO0721 - RAKE EXT. TERM. AT LOW EAVE WITHOUT SOFFIT
- DO0722 - RAKE EXT. TERM. AT LOW EAVE WITH SOFFIT (EAVE PURLIN)
- DO0723 - RAKE EXT. TERM. AT LOW EAVE WITHOUT SOFFIT (EAVE PURLIN)
- DO0724 - RAKE EXT. TERM. AT LOW EAVE WITH PERP. SOFFIT
- DO0725 - RAKE EXT. TERM. AT LOW EAVE WITH PERP. SOFFIT (EAVE PURLIN)

RAKE DETAILS

- DO0800 - RAKE TERM. AT EXT. / CANOPY WITH SOFFIT
 - DO0801 - RAKE TERM. AT EXT. / CANOPY WITHOUT SOFFIT
 - DO0802 - RAKE EXT. WITH PERP. SOFFIT
 - DO0810 - RAKE EXT. TRIM AT ENDWALL WITH SOFFIT
 - DO0811 - RAKE EXT. TRIM AT ENDWALL WITHOUT SOFFIT
 - DO0812 - RAKE EXT. TRIM AT ENDWALL WITH PERP. SOFFIT
 - DO0820 - RAKE CONT. AT EAVE EXT. WITH SOFFIT (BYPASS ENDWALL)
 - DO0821 - RAKE CONT. AT EAVE EXT. WITHOUT SOFFIT (BYPASS ENDWALL)
 - DO0830 - RAKE CONT. AT EAVE EXT. WITH SOFFIT (INSET / FLUSH ENDWALL)
 - DO0831 - RAKE CONT. AT EAVE EXT. WITHOUT SOFFIT (INSET / FLUSH ENDWALL)
 - DO0840 - RAKE CONT. AT CANOPY WITH SOFFIT (INSET / FLUSH ENDWALL)
-

HIGH EAVE DETAILS

DO0841 - RAKE CONT. AT CANOPY WITHOUT SOFFIT (INSET / FLUSH ENDWALL)

DO0900 - HIGH EAVE EXT. / CANOPY WITH SOFFIT

DO0901 - HIGH EAVE EXT. / CANOPY WITHOUT SOFFIT

DO0910 - INTERIOR HIGH EAVE AT BUILDING WITH SOFFIT

DO0911 - INTERIOR HIGH EAVE AT BUILDING WITHOUT SOFFIT

DO0920 - RAKE EXT. TERM. AT HIGH EAVE WITH SOFFIT

DO0921 - RAKE EXT. TERM. AT HIGH EAVE WITHOUT SOFFIT

DO0922 - RAKE EXT. TERM. AT HIGH EAVE WITHOUT SOFFIT


DO0005 - SOFFIT PANEL ERECTION DETAIL

[Download the DWG file by clicking here.](#)

- H1060 STITCH FASTENER
- H1040 STRUCTURAL FASTENER

ERECTOR NOTE:

ERECTION OF THE SOFFIT PANEL MUST BE COORDINATED PROPERLY WITH THE SOFFIT TRIM CONDITIONS AS SHOWN IN THE ERECTION DETAILS. PLACEMENT AND ORIENTATION OF THE SOFFIT PANEL MAY VARY BY CONDITION AND SUPPORT MEMBERS MAY ALSO VARY. USE THIS FASTENING PATTERN UNLESS TRIM SECTION SHOWS A SPECIFIC PATTERN.



SOFFIT PANEL ERECTION DETAIL

DO0005

Detailer Notes:

1) THIS DETAIL IS A DUPLICATE OF EO3005, EO6005, HK0005 & IK0005. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN THE ERECTION DRAWINGS.


DO0006 - URBAN SERIES SOFFIT PANEL ERECTION DETAIL

[Download the DWG file by clicking here.](#)

- H1060 STITCH FASTENER
- H1040 STRUCTURAL FASTENER
- NEGATIVE LOAD CLIP (MK. NLC-1)
(SEE FLAT SL PANEL ATTACHMENT DETAIL)

ERECTOR NOTE:

ERECTION OF THE SOFFIT PANEL MUST BE COORDINATED PROPERLY WITH THE SOFFIT TRIM CONDITIONS AS SHOWN IN THE ERECTION DETAILS. PLACEMENT AND ORIENTATION OF THE SOFFIT PANEL MAY VARY BY CONDITION AND SUPPORT MEMBERS MAY ALSO VARY. USE THIS FASTENING PATTERN UNLESS TRIM SECTION SHOWS A SPECIFIC PATTERN.



**METRO, SKYLINE & FLAT SL PANEL
SOFFIT ERECTION DETAIL**


DO0006

Detailer Notes:

1) THIS DETAIL IS A DUPLICATE OF EO3006, EO6006, HK0006 & IK0006. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN THE ERECTION DRAWINGS.

DO0007 - FLAT SL PANEL ATTACHMENT DETAIL

[Download the DWG file by clicking here.](#)



FLAT SL PANEL ATTACHMENT DETAIL
FLAT SL PANEL ATTACHMENT AT COLD FORM SECONDARY


DO0007

Detailer Notes:

- 1) THIS DETAIL IS A DUPLICATE OF DQ0007, EO3007, EO6007, EQ3007, EQ6007, HK0007, & IK0007. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN THE ERECTION DRAWINGS.

DO0510 - CANOPY SOFFIT TERMINATION AT BEAM

[Download the DWG file by clicking here.](#)



** ATTACH FLAT SL PANEL
TO TRIM WITH (1) H1100
POP RIVET AT 3'-0" O.C.

CANOPY SOFFIT TERMINATION AT BEAM

SEE SOFFIT PANEL ERECTION NOTE FOR SOFFIT PANEL FASTENER LOCATIONS


DO0510

Detailer Notes:

- 1) THIS DETAIL IS DUPLICATE OF EQ3510 & EQ6510. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN ERECTION DRAWINGS.

DO0610 - SOFFIT PANEL ENDLAP

Download the DWG file by clicking [here](#).



SOFFIT PANEL ENDLAP

DO0610

Detailer Notes:


- 1) N/A

DO0615 - SOFFIT PANEL - RIDGE \leq 1:12

Download the DWG file by clicking [here](#).

ERECTOR NOTE:

EXTEND THE PANEL PAST THE CENTERLINE OF THE RIDGE ON ONE SIDE OF THE RIDGE AS SHOWN. NEST THE OTHER PANEL INTO THE PROFILE.



SOFFIT PANEL RIDGE DETAIL

SOFFIT PANEL - SLOPES \leq 1:12
ALL STANDARD SOFFIT PANEL TYPES


DO0615

Detailer Notes:

- 1) N/A

DO0616 - SOFFIT PANEL - RIDGE > 1:12

[Download the DWG file by clicking here.](#)



SOFFIT PANEL RIDGE DETAIL

SOFFIT PANEL - SLOPES >1:12
ALL STANDARD SOFFIT PANEL TYPES


DO0616

Detailer Notes:

1) N/A

DO0617 - SOFFIT PANEL - METRO RIDGE TERMINATION

[Download the DWG file by clicking here.](#)



** IF PANEL SHOULD TERMINATE AT THE HIGH RIB,
ATTACH TO TRIM WITH H1100 POP RIVETS @ 1'-0" O.C.

METRO SOFFIT PANEL RIDGE DETAIL


DO0617

Detailer Notes:

1) N/A

DO0618 - SOFFIT PANEL - SKYLINE RIDGE TERMINATION

[Download the DWG file by clicking here.](#)



** IF PANEL SHOULD TERMINATE AT THE HIGH RIB,
ATTACH TO TRIM WITH H1100 POP RIVETS @ 1'-0" O.C.

SKYLINE SOFFIT PANEL RIDGE DETAIL


DO0618

Detailer Notes:

1) N/A

DO0619 - SOFFIT PANEL - FLAT SL PANEL RIDGE TERMINATION

[Download the DWG file by clicking here.](#)



FLAT SL PANEL SOFFIT RIDGE DETAIL

DO0619

Detailer Notes:


1) N/A

DO0700 - LOW EAVE EXTENSION / CANOPY WITH SOFFIT


[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.



GUTTER SHOWN IF REQ'D



LOW EAWE EXTENSION / CANOPY WITH SOFFIT

LOW EAWE WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0700

Detailer Notes:


- 1) N/A

DO0701 - LOW EAVE EXTENSION / CANOPY WITHOUT SOFFIT


[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.



GUTTER SHOWN IF REQ'D



LOW EAVE EXTENSION / CANOPY WITHOUT SOFFIT

LOW EAVE WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


DO0701

Detailer Notes:

- 1) N/A

DO0710 - INTERIOR LOW EAVE AT BUILDING WITH SOFFIT

[Download the DWG file by clicking here.](#)



INTERIOR LOW EAVE AT BUILDING WITH SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


DO0710

Detailer Notes:

- 1) N/A

DO0711 - INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)



INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


DO0711

Detailer Notes:

- 1) N/A

DO0712 - INTERIOR LOW EAVE AT BUILDING WITH SOFFIT (EAVE PURLIN)

[Download the DWG file by clicking here.](#)



INTERIOR LOW EAVE AT BUILDING WITH SOFFIT (EAVE PURLIN)

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


DO0712

Detailer Notes:

- 1) N/A

DO0713 - INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT (EAVE PURLIN)

[Download the DWG file by clicking here.](#)



INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT (EAVE PURLIN)

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0713

Detailer Notes:


- 1) N/A

DO0720 - RAKE EXTENSION TERMINATION AT LOW EAVE WITH SOFFIT

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



NOTE:
SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER

1 1/2" TAPE MASTIC MK. H3001 BETWEEN LBCRO_121 AND PANEL CLOSURE

R-PANEL ROOF

H1050 FASTENERS @ 12" O.C.

1/2" TAPE MASTIC H3010

GUTTER HANGER H2190 @ 2'-0" O.C. w/ (3) H1050 FASTENERS

GUTTER MK. GS

LOW EAVE TRIM LBCRO_121 W/ H1040 FASTENERS @ 1'-0" O.C.

LOW EAVE SOFFIT TRIM LES_121

5 1/4"

H1030 FASTENER (SEE THE ROOF STRUCTURAL FASTENER SPACING DETAIL)

INSIDE PANEL CLOSURE MK. CIRSO W/ 3/4" TAPE MASTIC MK. H3000 ON TOP

3/4" TAPE MASTIC MK. H3000 (6" PIECE) DIRECTLY BELOW FASTENERS

INSTALL LOW EAVE TRIM WITH TEMPORARY FASTENERS AT 1/3 POINTS INTO EAVE MEMBER UNTIL FINAL INSTALLATION OF SOFFIT TRIM.

H1040 FASTENERS @ 1'-0" O.C.

EAVE STRUT

SOFFIT PANEL

SOFFIT PANEL CLOSURE	
R-PANEL	COR
A-PANEL	COA
REV. R-PANEL	COV
FLAT SL PANEL	N/A
METRO	QC-169
SKYLINE	QC-104

H1060 FASTENERS @ 1'-0" O.C.

RAKE EXTENSION TERMINATION AT LOW EAVE WITH SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0720

Detailer Notes:


1) N/A

DO0721 - RAKE EXTENSION TERMINATION AT LOW EAVE WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



NOTE:
SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER

1 1/2" TAPE MASTIC MK. H3001 BETWEEN LBCRO_121 AND PANEL CLOSURE

R-PANEL ROOF

H1050 FASTENERS @ 12" O.C.


1/2" TAPE MASTIC H3010

GUTTER HANGER H2190 @ 2'-0" O.C. w/ (3) H1050 FASTENERS

GUTTER MK. GS

LOW EAVE TRIM LBCRO_121 w/ H1040 FASTENERS @ 1'-0" O.C.

LOW EAVE SOFFIT TRIM LES_121 w/ H1040 FASTENERS @ 1'-0" O.C.



INSTALL LOW EAVE TRIM WITH TEMPORARY FASTENERS AT 1/3 POINTS INTO EAVE MEMBER UNTIL FINAL INSTALLATION OF SOFFIT TRIM.

RAKE EXTENSION TERMINATION AT LOW EAVE WITHOUT SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0721

Detailer Notes:


- 1) N/A

DO0722 - RAKE EXTENSION TERMINATION AT LOW EAVE WITH SOFFIT (EAVE PURLIN)

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



NOTE:
SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER

- 1 1/2" TAPE MASTIC MK. H3001 BETWEEN LPCR_121 AND PANEL CLOSURE
- R-PANEL ROOF
- H1050 FASTENERS @ 12" O.C.
- 1/2" TAPE MASTIC H3010
- GUTTER HANGER H2190 @ 2'-0" O.C. w/ (3) H1050 FASTENERS

5 1/4" S

- H1030 FASTENER (SEE THE ROOF STRUCTURAL FASTENER SPACING DETAIL)
- INSIDE PANEL CLOSURE MK. CIRSO W/ 3/4" TAPE MASTIC MK. H3000 ON TOP
- 3/4" TAPE MASTIC MK. H3000 (6" PIECE) DIRECTLY BELOW FASTENERS

INSTALL LOW EAVE TRIM WITH TEMPORARY FASTENERS AT 1/3 POINTS INTO EAVE MEMBER UNTIL FINAL INSTALLATION OF SOFFIT TRIM.

- GUTTER MK. GS
- LOW EAVE TRIM LPCR_121 W/ H1040 FASTENERS @ 1'-0" O.C.

- H1040 FASTENERS @ 1'-0" O.C.
- EAVE PURLIN
- SOFFIT PANEL

- H1050 FASTENERS @ 1'-0" O.C.

- LOW EAVE SOFFIT TRIM LPWS_121

SOFFIT PANEL CLOSURE	
R-PANEL	COR
A-PANEL	COA
REV. R-PANEL	COV
FLAT SL PANEL	N/A
METRO	QC-169
SKYLINE	QC-104

RAKE EXTENSION TERMINATION AT LOW EAVE WITH SOFFIT (EAVE PURLIN)

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0722

Detailer Notes:


- 1) N/A

DO0723 - RAKE EXTENSION TERMINATION AT LOW EAVE WITHOUT SOFFIT (EAVE PURLIN)

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



NOTE:
SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER

1 1/2" TAPE MASTIC MK. H3001 BETWEEN LPCR_121 AND PANEL CLOSURE
R-PANEL ROOF
H1050 FASTENERS @ 12" O.C.

1/2" TAPE MASTIC H3010

GUTTER HANGER H2190 @ 2'-0" O.C. w/ (3) H1050 FASTENERS

GUTTER MK. GS
LOW EAVE TRIM MK. LPCR_121 W/ H1040 FASTENERS @ 1'-0" O.C.

LOW EAVE SOFFIT TRIM MK. LPNS_121 W/ H1040 FASTENERS @ 1'-0" O.C.

5 1/4" S

H1030 FASTENER (SEE THE ROOF STRUCTURAL FASTENER SPACING DETAIL)

INSIDE PANEL CLOSURE MK. CIRSO W/ 3/4" TAPE MASTIC MK. H3000 ON TOP

3/4" TAPE MASTIC MK. H3000 (6" PIECE) DIRECTLY BELOW FASTENERS

EAVE PURLIN

INSTALL LOW EAVE TRIM WITH TEMPORARY FASTENERS AT 1/3 POINTS INTO EAVE MEMBER UNTIL FINAL INSTALLATION OF SOFFIT TRIM.

RAKE EXTENSION TERMINATION AT LOW EAVE WITHOUT SOFFIT (EAVE PURLIN)

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0723

Detailer Notes:


1) N/A

DO0724 - RAKE EXTENSION TERMINATION AT LOW EAVE WITH PERPENDICULAR SOFFIT

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.




NOTE:
SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

GUTTER SHOWN IF REQ'D

☐ REQ'D ONLY FOR GUTTER

- ☐ 1 1/2" TAPE MASTIC MK. H3001 BETWEEN LBCR_121 AND PANEL CLOSURE
- ☐ H1050 FASTENERS @ 12" O.C.
- ☐ 1/2" TAPE MASTIC H3010
- ☐ GUTTER HANGER H2190 @ 2'-0" O.C. w/ (3) H1050 FASTENERS

- ☐ GUTTER MK. GS
- LOW EAVE TRIM LBCRO_121 W/ H1040 FASTENERS @ 1'-0" O.C.
- LOW EAVE SOFFIT TRIM LES_121 W/ H1040 FASTENERS @ 1'-0" O.C.



INSTALL LOW EAVE TRIM WITH TEMPORARY FASTENERS AT 1/3 POINTS INTO EAVE MEMBER UNTIL FINAL INSTALLATION OF SOFFIT TRIM.

RAKE EXTENSION TERMINATION AT LOW EAVE WITH PERPENDICULAR SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0724

Detailer Notes:


- 1) N/A

DO0725 - RAKE EXTENSION TERMINATION AT LOW EAVE WITH PERPENDICULAR SOFFIT (EAVE PURLIN)

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.




NOTE:
SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER

- 1 1/2" TAPE MASTIC MK. H3001 BETWEEN LBCR_121 AND PANEL CLOSURE
- R-PANEL ROOF
- H1050 FASTENERS @ 12" O.C.
- 1/2" TAPE MASTIC H3010
- GUTTER HANGER H2190 @ 2'-0" O.C. w/ (3) H1050 FASTENERS



RAKE EXTENSION TERMINATION AT LOW EAVE WITH PERPENDICULAR SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0725

Detailer Notes:


- 1) N/A

DO0800 - RAKE TERMINATION AT EXTENSION / CANOPY WITH SOFFIT

[Download the DWG file by clicking here.](#)


RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER



RAKE TERMINATION AT EXTENSION / CANOPY WITH SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0800

Detailer Notes:


- 1) N/A

DO0801 - RAKE TERMINATION AT EXTENSION / CANOPY WITHOUT SOFFIT


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



**NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER**



**RAKE TERMINATION AT EXTENSION / CANOPY
WITHOUT SOFFIT**

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0801

Detailer Notes:


- 1) N/A

DO0802 - RAKE EXTENSION WITH PERPENDICULAR SOFFIT


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: REFERENCE DETAIL DA0076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



RAKE EXTENSION WITH PERPENDICULAR SOFFIT

RAKE EXTENSION w / SOFFIT PANEL PERPENDICULAR TO WALL
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


DO0802

Detailer Notes:

- 1) N/A

DO0810 - RAKE EXTENSION TRIM AT ENDWALL WITH SOFFIT

[Download the DWG file by clicking here.](#)



RAKE EXTENSION TRIM AT ENDWALL WITH SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS



DO0810

Detailer Notes:

- 1) N/A

DO0811 - RAKE EXTENSION TRIM AT ENDWALL WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)



PARTITION FLASHING MUST BE CUT TO LENGTH AND NOTCHED IN THE FIELD. FIELD WORK OF FLASHING WILL BE REQUIRED AT ALL PURLINS, EAVES AND RIDGES.

PARTITION TRIM CUTOUT FOR PURLINS

RAKE EXTENSION TRIM AT ENDWALL WITHOUT SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


DO0811

Detailer Notes:

- 1) N/A

DO0812 - RAKE EXTENSION TRIM AT ENDWALL WITH PERPENDICULAR SOFFIT

[Download the DWG file by clicking here.](#)



**RAKE EXTENSION TRIM AT ENDWALL
WITH PERPENDICULAR SOFFIT**

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0812

Detailer Notes:


- 1) N/A

DO0820 - RAKE CONTINUATION AT EAVE EXTENSION WITH SOFFIT (BYPASS ENDWALL)

[Download the DWG file by clicking here.](#)


RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER



RAKE CONTINUATION AT EAVE EXTENSION WITH SOFFIT (BYPASS ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0820

Detailer Notes:


- 1) USE THIS DETAIL WITH BYPASS ENDWALL CONDITIONS.

DO0821 - RAKE CONTINUATION AT EAVE EXTENSION WITHOUT SOFFIT (BYPASS ENDWALL)

[Download the DWG file by clicking here.](#)


RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER



RAKE CONTINUATION AT EAVE EXTENSION
WITHOUT SOFFIT (BYPASS ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0821

Detailer Notes:


- 1) USE THIS DETAIL WITH BYPASS ENDWALL CONDITIONS.

DO0830 - RAKE CONTINUATION AT EAVE EXTENSION WITH SOFFIT (INSET / FLUSH ENDWALL)

[Download the DWG file by clicking here.](#)


RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER



RAKE CONTINUATION AT EAVE EXTENSION
WITH SOFFIT (INSET / FLUSH ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0830

Detailer Notes:


- 1) USE THIS DETAIL WITH FLUSH OR INSET ENDWALL CONDITIONS.

DO0831 - RAKE CONTINUATION AT EAVE EXTENSION WITHOUT SOFFIT (INSET / FLUSH ENDWALL)


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



**NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER**



**RAKE CONTINUATION AT EAVE EXTENSION
WITHOUT SOFFIT (INSET / FLUSH ENDWALL)**

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0831

Detailer Notes:


- 1) USE THIS DETAIL WITH FLUSH OR INSET ENDWALL CONDITIONS.

DO0840 - RAKE CONTINUATION AT CANOPY WITH SOFFIT (INSET / FLUSH ENDWALL)


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: REFERENCE DETAIL DA0076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



RAKE CONTINUATION AT CANOPY WITH SOFFIT (INSET / FLUSH ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0840

Detailer Notes:


- 1) USE THIS DETAIL WITH FLUSH OR INSET ENDWALL CONDITIONS.

DO0841 - RAKE CONTINUATION AT CANOPY WITHOUT SOFFIT (INSET / FLUSH ENDWALL)

[Download the DWG file by clicking here.](#)


RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER



RAKE CONTINUATION AT CANOPY
WITHOUT SOFFIT (INSET / FLUSH ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0841

Detailer Notes:


- 1) USE THIS DETAIL WITH FLUSH OR INSET ENDWALL CONDITIONS.

DO0900 - HIGH EAVE EXTENSION / CANOPY WITH SOFFIT


[Download the DWG file by clicking here.](#)

HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



NOTE 1: REFERENCE DETAIL DA0076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



HIGH EAVE EXTENSION / CANOPY WITH SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0900

Detailer Notes:


1) EXTENSIONS BETWEEN 1'-3" AND 1'-8" - PURLIN WILL INTERFERE WITH WALL PANEL AND DETAIL WILL HAVE TO BE MODIFIED TO ADJUST WALL PANEL SET DOWN TO KEEP PURLIN AT 1'-4" FROM STEEL LINE.

DO0901 - HIGH EAVE EXTENSION / CANOPY WITHOUT SOFFIT


[Download the DWG file by clicking here.](#)

HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



**NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER**



**HIGH EAVE EXTENSION / CANOPY
WITHOUT SOFFIT**

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


DO0901

Detailer Notes:

- 1) EXTENSIONS BETWEEN 1'-3" AND 1'-8" - PURLIN WILL INTERFERE WITH WALL PANEL AND DETAIL WILL HAVE TO BE MODIFIED TO ADJUST WALL PANEL SET DOWN TO KEEP PURLIN AT 1'-4" FROM STEEL LINE.

DO0910 - INTERIOR HIGH EAVE AT BUILDING WITH SOFFIT

[Download the DWG file by clicking here.](#)



* ALTERNATE FASTENER LOCATION FOR LOWER SLOPED ROOFS. MAL ANGLE NOT REQ'D WHEN USING ALTERNATE FASTENER

INTERIOR HIGH EAVE AT BUILDING WITH SOFFIT

HIGH EAVE WITH EAVE EXTENSION OR AT-EAVE CANOPY
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


DO0910

Detailer Notes:

- 1) EXTENSIONS BETWEEN 1'-3" AND 1'-8" - PURLIN WILL INTERFERE WITH WALL PANEL AND DETAIL WILL HAVE TO BE MODIFIED TO ADJUST WALL PANEL SET DOWN TO KEEP PURLIN AT 1'-4" FROM STEEL LINE.

DO0911 - INTERIOR HIGH EAVE AT BUILDING WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)



**INTERIOR HIGH EAVE AT BUILDING
WITHOUT SOFFIT**

HIGH EAVE WITH EAVE EXTENSION, OR AT-EAVE CANOPY SEE WALL SHEETING
ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0911

Detailer Notes:


- 1) EXTENSIONS BETWEEN 1'-3" AND 1'-8" - PURLIN WILL INTERFERE WITH WALL PANEL AND DETAIL WILL HAVE TO BE MODIFIED TO ADJUST WALL PANEL SET DOWN TO KEEP PURLIN AT 1'-4" FROM STEEL LINE.

DO0920 - RAKE EXTENSION TERMINATION AT HIGH EAVE WITH SOFFIT


[Download the DWG file by clicking here.](#)

HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



**NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER**



**RAKE EXTENSION TERMINATION
AT HIGH EAVE WITH SOFFIT**

HIGH EAVE WITH EAVE EXTENSION OR AT-EAVE CANOPY
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0920

Detailer Notes:


- 1) N/A

DO0921 - RAKE EXTENSION TERMINATION AT HIGH EAVE WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)


HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER



RAKE EXTENSION TERMINATION
AT HIGH EAVE WITHOUT SOFFIT

HIGH EAVE WITH EAVE EXTENSION OR AT-EAVE CANOPY
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0921

Detailer Notes:


- 1) N/A

DO0922 - RAKE EXTENSION TERMINATION AT HIGH EAVE WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)


HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL
DA0076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER



RAKE EXTENSION TERMINATION
AT HIGH EAVE WITH PERPENDICULAR SOFFIT

HIGH EAVE WITH EAVE EXTENSION OR AT-EAVE CANOPY
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

DO0922

Detailer Notes:

- 1) N/A