


**LOW EAVE (GUTTER)**

- ED3005 - GUTTER EXTENSION TRIM
  - ED3010 - ON-SLOPE GUTTER - WALL PANEL
  - ED3040 - ON-SLOPE GUTTER - MASONRY WALL
  - ED3050 - ON-SLOPE GUTTER - SUPPORTING MASONRY WALL
  - ED3070 - ON-SLOPE GUTTER - NO WALL PANEL
  - ED3310 - HORIZONTAL GUTTER - WALL PANEL
  - ED3410 - HORIZONTAL GUTTER - MASONRY WALL
  - ED3610 - ON-SLOPE GUTTER - INSULATED WALL PANEL
  - ED3620 - HORIZONTAL GUTTER - INSULATED WALL PANEL
-

ED3005 - GUTTER EXTENSION TRIM

[Download the DWG file by clicking here.](#)

**NOTE: IT IS RECOMMENDED TO TEMPORARILY FASTEN THE GUTTER EXTENSION TRIM TO THE GUTTER PRIOR TO INSTALLING GUTTER WITH POP RIVETS. THEN INSTALL FASTENERS AT TIME OF GUTTER INSTALLATION. SEE THE GUTTER INSTALLATION DETAIL FOR FURTHER INSTRUCTIONS.**



## GUTTER EXTENSION TRIM DETAIL

OPTIONAL GUTTER EXTENSION TRIM DETAIL

**ED3005**

Detailer Notes:


- 1) THIS DETAIL CAN BE USED WITH ANY PANEL TYPE - LOC SEAM / TRAPEZOIDAL / IMP / R-PANEL

## ED3010 - ON-SLOPE GUTTER w/ WALL PANEL

[Download the DWG file by clicking here.](#)

### GUTTER LAP & END CAP


APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



**NOTE 1: PANEL RIB MUST BE HAND CRIMPED 90°  
(NOT 360°) PRIOR TO INSTALLING GUTTER BRACKET!**

### NOTE:

SEE ROOF PANEL BASIC  
INSTALLATION DETAIL EA3011  
FOR FASTENER AND SEALANT  
REQUIREMENTS



### ON-SLOPE GUTTER DETAIL

EAVE GUTTER DETAIL w/ WALL PANELS  
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

**ED3010**

### Detailer Notes:


- 1) CLOSURES LOW EAVE LAYER DEFAULT IS ON. LAYER MUST BE TURNED OFF IF CLOSURES ARE NOT REQUIRED.

## ED3040 - ON-SLOPE GUTTER w/ MASONRY WALL

[Download the DWG file by clicking here.](#)


### GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



**NOTE 1: PANEL RIB MUST BE HAND CRIMPED 90°  
(NOT 360°) PRIOR TO INSTALLING GUTTER BRACKET!**

**NOTE:**  
SEE ROOF PANEL BASIC  
INSTALLATION DETAIL EA3011  
FOR FASTENER AND SEALANT  
REQUIREMENTS



### ON-SLOPE GUTTER DETAIL

EAVE GUTTER DETAIL w/ MASONRY WALL

ED3040

### Detailer Notes:


1) N/A

## ED3050 - ON-SLOPE GUTTER w/ SUPPORTING MASONRY WALL

[Download the DWG file by clicking here.](#)


### GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



**NOTE 1: PANEL RIB MUST BE HAND CRIMPED 90°  
(NOT 360°) PRIOR TO INSTALLING GUTTER BRACKET!**

**NOTE:**  
SEE ROOF PANEL BASIC  
INSTALLATION DETAIL EA3011  
FOR FASTENER AND SEALANT  
REQUIREMENTS



### ON-SLOPE GUTTER DETAIL

EAVE GUTTER DETAIL w/ SUPPORTING MASONRY WALL

**ED3050**

### Detailer Notes:


1) N/A

## ED3070 - ON-SLOPE GUTTER w/ NO WALL PANEL

[Download the DWG file by clicking here.](#)

### GUTTER LAP & END CAP


APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



**NOTE 1: PANEL RIB MUST BE HAND CRIMPED 90°  
(NOT 360°) PRIOR TO INSTALLING GUTTER BRACKET!**

### NOTE:

SEE ROOF PANEL BASIC  
INSTALLATION DETAIL EA3011  
FOR FASTENER AND SEALANT  
REQUIREMENTS



### ON-SLOPE GUTTER DETAIL

EAVE GUTTER DETAIL w/ NO WALL PANEL

ED3070


### Detailer Notes:

1) N/A

**ED3310 - HORIZONTAL GUTTER w/ WALL PANEL**

Download the DWG file by clicking [here](#).

**NOTE:**  
SEE ROOF PANEL BASIC  
INSTALLATION DETAIL EA3011  
FOR FASTENER AND SEALANT  
REQUIREMENTS





**HORIZONTAL GUTTER - Loc Seam ROOF**

WALL PANEL AT SCULPTURED RAKE

**NOTE:** FASTENERS ARE PROVIDED IN COLORS TO MATCH THE INDIVIDUAL COMPONENTS. THE (4) GUTTER BRACKET TO GUTTER ANGLE FASTENERS ARE ROOF LINE TRIM COLOR.

**GUTTER LAP & END CAP**

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



**ISOMETRIC VIEW OF HORIZONTAL GUTTER SYSTEM**

EAVE ANGLE & EAVE ZEE SHOWN FOR REFERENCE ONLY, ACTUAL EAVE MEMBER MAY VARY

**NOTE:** THE BEGINNING OF THIS ASSEMBLY PROCESS ASSUMES THE ROOF PANEL & WALL PANEL ARE COMPLETELY INSTALLED

THE PURPOSE OF THE POSITIONING TRIM IS TO ALLOW ADJUSTMENT OF THE GUTTER ANGLE SO THAT IT CAN BE ALIGNED PLUMB. IT ALSO PROVIDES ADJUSTMENT IN THE EVENT THE WALL IS NOT STRAIGHT AND IT ALSO HIDES ANY UNPAINTED MATERIALS.

IT IS RECOMMENDED TO HOLD THE GHP121 1" SHORT OF THE OUTSIDE EDGE OF THE WALL CORNER TRIM.

**STEP 1**

MEASURE DOWN 5 1/4" FROM THE BOTTOM OF ROOF PANEL & MARK THE WALL PANEL. INSTALL THE GHP121 AT THIS LOCATION. LEAVE A 1/8" TO 1/4" GAP AT GHP121 ENDS. DO NOT LAP THEM. INSTALL THE WALL PANEL CLOSURE AT THE SAME TIME AS THE GHP121 TRIM IS INSTALLED.

**NOTE:** THE ALIGNMENT OF THE GUTTER ANGLE IS CRITICAL TO THE FINAL APPEARANCE AND STRAIGHTNESS OF THE HORIZONTAL GUTTER SYSTEM.

READ STEP 3 "OPTIONAL INSTALLATION" NOTES BEFORE PROCEEDING WITH STEP 2.

(3) H1030 PER FLAT OF PANEL

1 1/2" TAPE MASTIC H3001

**GUTTER ANGLE LAP NOTES**


AT GUTTER ANGLE ENDS, BUTT THE PIECES TOGETHER, DO NOT LAP THEM.

**IMPORTANT NOTE**

AT GUTTER ENDS, HOLD THE GUTTER ANGLE FLUSH WITH THE END OF GHP121 TRIM.

**STEP 2**

APPLY TAPE MASTIC TO THE GUTTER ANGLE AS SHOWN. ALIGN & CLAMP THE GUTTER ANGLE TO THE ROOF PANEL. FASTEN THE GUTTER ANGLE TO THE ROOF PANEL. PLUMB THE GUTTER ANGLE AND FASTEN THE GHP121 TO THE GUTTER ANGLE.




**NOTE:** THIS STEP CAN BE COMPLETED ON THE GROUND. ALSO, HOLD THE BRACKET AT END PIECE OF GUTTER APPROXIMATELY 1'-3" FROM THE END OF THE GUTTER TO ALLOW ROOM FOR RAKE TRIM TRANSITION INTO THE GUTTER.

**OPTIONAL INSTALLATION**

IF DESIRED, STEPS 2 AND 3 CAN BE COMBINED AND DONE ON THE GROUND. IF THAT IS DONE, THE PANCAKE HEAD FASTENER WOULD NOT BE REQUIRED. INSTEAD, ATTACH THE (4) H1030 FASTENERS IN THE BACK OF THE GUTTER BRACKET, THROUGH THE GUTTER ANGLE. THIS ASSEMBLY CAN THEN BE LIFTED IN PLACE AS A SINGLE UNIT. THIS PROCEDURE IS MERELY OPTIONAL AND NOT RECOMMENDED FOR LONG BUILDINGS.


H3000 TAPE MASTIC CAN BE PLACED IN EITHER LOCATION SHOWN HERE



**STEP 3**

MARK THE LOCATIONS OF THE GUTTER BRACKETS, BASED ON THE SPACING SHOWN ABOVE LEFT. APPLY TAPE MASTIC TO THE VERTICAL BACK LEGS OF THE BRACKETS. INSTALL AN H1220 FASTENER AT THE BACK LIP OF THE GUTTER ONLY AT THIS TIME. APPLY TAPE MASTIC ALONG THE FULL LENGTH OF THE TOP OF THE BACK LIP OF THE GUTTER AS SHOWN.


**NOTE:** BE SURE TO COMPRESS THE MASTIC ALONG THE TOP, BACK LIP OF THE GUTTER INTO THE GUTTER ANGLE TO PREVENT WATER FROM WICKING BACK BEHIND THE GUTTER.



**STEP 4**

LIFT THE GUTTER IN PLACE, TEMPORARILY CLAMPING IT TO THE GUTTER ANGLE. PULL THE FRONT FACE OF THE GUTTER FORWARD TO ALLOW ACCESS TO INSTALL THE (4) FASTENERS THROUGH THE BACK OF THE BRACKET & GUTTER, INTO THE GUTTER ANGLE. DO NOT YET INSTALL THE FASTENER AT THE OUTER LIP OF THE GUTTER.


**NOTE:** IF THE OPTIONAL GUTTER SUPPORT ANGLE IS REQUIRED IN THE DETAIL, SKIP TO STEP 6. IF IT IS NOT REQUIRED, CONTINUE WITH STEP 5. REFER TO THE DETAIL AT TOP LEFT TO DETERMINE WHETHER OR NOT IT IS REQUIRED.



**STEP 5**

AFTER THE (4) FASTENERS ARE INSTALLED THROUGH THE GUTTER BRACKETS & INTO THE GUTTER ANGLE, ALONG THE ENTIRE LENGTH OF A SECTION OF GUTTER, THE FASTENER AT THE FRONT LIP OF THE GUTTER CAN BE INSTALLED. CLAMPING THE BRACKET TO THE GUTTER FACILITATES EASIER INSTALLATION.

**NOTE:** IF THE OPTIONAL GUTTER SUPPORT ANGLE IS REQUIRED, IT CAN BE INSTALLED AT THIS TIME. THE FASTENER AT THE FRONT LIP OF THE GUTTER WILL GO THROUGH THE GUTTER, GUTTER SUPPORT ANGLE, AND THE GUTTER BRACKET.



**STEP 6**

AFTER THE (4) FASTENERS ARE INSTALLED THROUGH THE GUTTER BRACKETS & INTO THE GUTTER ANGLE, ALONG THE ENTIRE LENGTH OF A SECTION OF GUTTER, THE FASTENER AT THE FRONT LIP OF THE GUTTER CAN BE INSTALLED. CLAMPING THE BRACKET & GUTTER SUPPORT ANGLE BRACKET TO THE GUTTER FACILITATES EASIER INSTALLATION.

**SUPPORT ANGLE NOTES**  
AT THE END PIECES OF GUTTER, HOLD THE GUTTER SUPPORT ANGLE 2" FROM THE END OF THE GUTTER. THIS WILL KEEP IT OUT OF THE WAY OF THE GUTTER END CAP WHEN THOSE ARE INSTALLED (SEE CORNER DETAIL).


**ED3310**

**Detailer Notes:**

1) CLOSURES LOW EAVE LAYER DEFAULT IS ON. LAYER MUST BE TURNED OFF IF CLOSURES ARE NOT REQUIRED.

**ED3410 - HORIZONTAL GUTTER w/ MASONRY WALL**

[Download the DWG file by clicking here.](#)





**HORIZONTAL GUTTER - Loc Seam ROOF**

HORIZONTAL GUTTER AT MASONRY WALL

**NOTE:** FASTENERS ARE PROVIDED IN COLORS TO  
MATCH THE INDIVIDUAL COMPONENTS. THE (4)  
GUTTER BRACKET TO GUTTER ANGLE  
FASTENERS ARE ROOF LINE TRIM COLOR.

**GUTTER LAP & END CAP**

APPLY BEAD OF POLYURETHANE CAULK 1\" FROM END OF TRIM AND LAP SECTIONS 2\" AND FASTEN AS  
SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP  
RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2\" EXPOSED. ATTACH WITH RIVETS  
SAME AS END LAP.



**ISOMETRIC VIEW OF HORIZONTAL GUTTER SYSTEM**


**NOTE:** THE BEGINNING OF THIS ASSEMBLY PROCESS ASSUMES  
THE ROOF PANEL & WALL PANEL ARE COMPLETELY INSTALLED

THE PURPOSE OF THE  
POSITIONING TRIM IS TO ALLOW  
ADJUSTMENT OF THE GUTTER  
ANGLE SO THAT IT CAN BE  
ALIGNED PLUMB. IT ALSO  
PROVIDES ADJUSTMENT IN THE  
EVENT THE WALL IS NOT  
STRAIGHT AND IT ALSO HIDES  
ANY UNPAINTED MATERIALS.

IT IS RECOMMENDED TO HOLD THE  
GHP121 1\" SHORT OF THE OUTSIDE  
EDGE OF THE WALL CORNER TRIM.

**STEP 1**

MEASURE DOWN 5 1/4\" FROM THE BOTTOM OF ROOF PANEL & MARK THE WALL. INSTALL THE GHP121 AT THIS  
LOCATION. LEAVE A 1/8\" TO 1/4\" GAP AT GHP121 ENDS. DO NOT LAP THEM.



**NOTE:** THE ALIGNMENT OF THE GUTTER ANGLE IS CRITICAL TO  
THE FINAL APPEARANCE AND STRAIGHTNESS OF THE  
HORIZONTAL GUTTER SYSTEM.

READ STEP 3 \"OPTIONAL  
INSTALLATION\" NOTES BEFORE  
PROCEEDING WITH STEP 2

(4) H1030 PER FLAT OF PANEL

1 1/2\" TAPE MASTIC H3001

**GUTTER ANGLE LAP NOTES**


AT GUTTER ANGLE ENDS, BUTT THE PIECES  
TOGETHER. DO NOT LAP THEM.

**IMPORTANT NOTE**

AT GUTTER ENDS, HOLD THE GUTTER ANGLE FLUSH  
WITH THE END OF GHP121 TRIM.

**STEP 2**

APPLY TAPE MASTIC TO THE GUTTER ANGLE AS SHOWN. ALIGN & CLAMP THE GUTTER ANGLE TO THE ROOF PANEL.  
FASTEN THE GUTTER ANGLE TO THE ROOF PANEL. PLUMB THE GUTTER ANGLE AND FASTEN THE GHP121 TO THE  
GUTTER ANGLE.



**NOTE:** THIS STEP CAN BE COMPLETED ON THE GROUND. ALSO, HOLD THE BRACKET AT END PIECE OF GUTTER  
APPROXIMATELY 1'-0\" FROM THE END OF THE GUTTER TO ALLOW ROOM FOR RAKE TRIM TRANSITION INTO THE GUTTER.

**OPTIONAL INSTALLATION**

IF DESIRED, STEPS 2 AND 3 CAN BE COMBINED  
AND DONE. ON THE GROUND. IF THAT IS DONE,  
THE PANCAKE HEAD FASTENER WOULD NOT  
BE REQUIRED. INSTEAD, ATTACH THE (4) H1030  
FASTENERS IN THE BACK OF THE GUTTER  
BRACKET, THROUGH THE GUTTER ANGLE. THIS  
ASSEMBLY CAN THEN BE LIFTED IN PLACE AS A  
SINGLE UNIT. THIS PROCEDURE IS MERELY  
OPTIONAL AND NOT RECOMMENDED FOR LONG  
BUILDINGS.

H3000 TAPE MASTIC CAN BE PLACED IN  
EITHER LOCATION SHOWN HERE

CONTINUOUS H3000 3/4\"  
TAPE MASTIC (SEE  
NOTE ABOVE)

GUTTER BRACKET  
MK. H2210

PANCAKE HEAD  
FASTENER MK.  
H1220

GUTTER  
MK. GS. ....

3/4\" TAPE MASTIC  
H3000

BACK LEG  
OF GUTTER

**STEP 3**

MARK THE LOCATIONS OF THE GUTTER BRACKETS, BASED ON THE SPACING SHOWN ABOVE. LEFT. APPLY TAPE MASTIC  
TO THE VERTICAL BACK LEGS OF THE BRACKETS. INSTALL AN H1220 FASTENER AT THE BACK LIP OF THE GUTTER ONLY  
AT THIS TIME. APPLY TAPE MASTIC ALONG THE FULL LENGTH OF THE TOP OF THE BACK LIP OF THE GUTTER AS SHOWN.


**NOTE:** BE SURE TO COMPRESS THE MASTIC ALONG THE TOP,  
BACK LIP OF THE GUTTER INTO THE GUTTER ANGLE TO  
PREVENT WATER FROM WICKING BACK BEHIND THE GUTTER.

3/4\" H3000 TAPE MASTIC  
BETWEEN GUTTER & GUTTER  
ANGLE

GUTTER BRACKET MK. H2210,  
WITH (4) H1030 FASTENERS  
AND H3000 TAPE MASTIC

**STEP 4**

LIFT THE GUTTER IN PLACE, TEMPORARILY CLAMPING IT TO THE GUTTER ANGLE. PULL THE FRONT FACE OF THE  
GUTTER FORWARD TO ALLOW ACCESS TO INSTALL THE (4) FASTENERS THROUGH THE BACK OF THE BRACKET &  
GUTTER, INTO THE GUTTER ANGLE. DO NOT YET INSTALL THE FASTENER AT THE OUTER LIP OF THE GUTTER.




**NOTE:** IF THE OPTIONAL GUTTER SUPPORT ANGLE IS  
REQUIRED IN THE DETAIL, SKIP TO STEP 6. IF IT IS NOT  
REQUIRED, CONTINUE WITH STEP 5. REFER TO THE DETAIL AT  
TOP LEFT TO DETERMINE WHETHER OR NOT IT IS REQUIRED.

(1) H1030  
FASTENER PER  
BRACKET

**STEP 5**

AFTER THE (4) FASTENERS ARE INSTALLED THROUGH THE GUTTER BRACKETS & INTO THE GUTTER ANGLE, ALONG THE  
ENTIRE LENGTH OF A SECTION OF GUTTER, THE FASTENER AT THE FRONT LIP OF THE GUTTER CAN BE INSTALLED.  
CLAMPING THE BRACKET TO THE GUTTER FACILITATES EASIER INSTALLATION.




**NOTE:** IF THE OPTIONAL GUTTER SUPPORT ANGLE IS  
REQUIRED, IT CAN BE INSTALLED AT THIS TIME. THE FASTENER  
AT THE FRONT LIP OF THE GUTTER WILL GO THROUGH THE  
GUTTER, GUTTER SUPPORT ANGLE, AND THE GUTTER  
BRACKET.

(1) H1030  
FASTENER PER  
BRACKET

**STEP 6**

AFTER THE (4) FASTENERS ARE INSTALLED THROUGH THE GUTTER BRACKETS & INTO THE GUTTER ANGLE, ALONG THE  
ENTIRE LENGTH OF A SECTION OF GUTTER, THE FASTENER AT THE FRONT LIP OF THE  
GUTTER CAN BE INSTALLED. CLAMPING THE BRACKET & GUTTER SUPPORT ANGLE  
BRACKET TO THE GUTTER FACILITATES EASIER INSTALLATION.



**ED3410**

**Detailer Notes:**

1) CLOSURES LOW EAVE LAYER DEFAULT IS ON. LAYER MUST BE TURNED OFF IF CLOSURES ARE NOT  
REQUIRED.




ED3610 - ON-SLOPE GUTTER w/ INSULATED WALL PANEL

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



**NOTE 1: PANEL RIB MUST BE  
HAND CRIMPED 90° (NOT 360°)  
PRIOR TO INSTALLING GUTTER  
BRACKET!**

OVERHANG DIMENSION		
** THICKNESS	* OVERHANG	LBI 121
2"	6"	LBI20121
2 1/2"	6 1/2"	LBI25121
3"	7"	LBI30121
4"	8"	LBI40121

**NOTE:**


SEE ROOF PANEL BASIC  
INSTALLATION DETAIL EA3011  
FOR FASTENER AND SEALANT  
REQUIREMENTS

(3) H1050 PER PANEL  
SPACED EQUALLY

1/2" TAPE MASTIC  
H3010

GUTTER HANGER  
H4640 w/ (3) H1050  
FASTENERS

16" O.C.  
X 32" O.C.



ON-SLOPE GUTTER DETAIL

EAVE GUTTER DETAIL w/ INSULATED WALL PANELS  
SEE INSULATED WALL SHEETING ERECTION DETAILS FOR INSTALLATION  
INSTRUCTIONS.

ED3610


Detailer Notes:

1) N/A

**ED3620 - HORIZONTAL GUTTER w/ INSULATED WALL PANEL**

Download the DWG file by clicking [here](#).

**NOTE:**  
SEE ROOF PANEL BASIC  
INSTALLATION DETAIL EA3011  
FOR FASTENER AND SEALANT  
REQUIREMENTS





**HORIZONTAL GUTTER - Loc Seam ROOF**

WALL PANEL AT SOUP'URED RAKE

**NOTE:** FASTENERS ARE PROVIDED IN COLORS TO  
MATCH THE INDIVIDUAL COMPONENTS. THE (4)  
GUTTER BRACKET TO GUTTER ANGLE  
FASTENERS ARE ROOF LINE TRIM COLOR.

**GUTTER LAP & END CAP**

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT INTO THE GUTTER LEAVING 1/2" EXPOSED. ATTACH WITH RIVETS SAME AS END LAP.



**ISOMETRIC VIEW OF HORIZONTAL GUTTER SYSTEM**

EAVE ANGLE & EAVE ZEE SHOWN FOR REFERENCE ONLY, ACTUAL EAVE MEMBER MAY VARY


**NOTE:** THE BEGINNING OF THIS ASSEMBLY PROCESS ASSUMES  
THE ROOF PANEL & WALL PANEL ARE COMPLETELY INSTALLED

THE PURPOSE OF THE  
POSITIONING TRIM IS TO ALLOW  
ADJUSTMENT OF THE GUTTER  
ANGLE SO THAT IT CAN BE  
ALIGNED PLUMB. IT ALSO  
PROVIDES ADJUSTMENT IN THE  
EVENT THE WALL IS NOT  
STRAIGHT AND IT ALSO HIDES  
ANY UNPAINTED MATERIALS.

IT IS RECOMMENDED TO HOLD THE  
GHP121 1" SHORT OF THE OUTSIDE  
EDGE OF THE WALL CORNER TRIM.

**STEP 1**

MEASURE DOWN 5 1/4" FROM THE BOTTOM OF ROOF PANEL & MARK THE WALL PANEL. INSTALL THE GHP121 AT THIS LOCATION. LEAVE A 1/8" TO 1/4" GAP AT GHP121 ENDS. DO NOT LAP THEM.



**NOTE:** THE ALIGNMENT OF THE GUTTER ANGLE IS CRITICAL TO  
THE FINAL APPEARANCE AND STRAIGHTNESS OF THE  
HORIZONTAL GUTTER SYSTEM.

**READ STEP 3 \*OPTIONAL  
INSTALLATION\* NOTES BEFORE  
PROCEEDING WITH STEP 2.**

(4) H1030 PER FLAT OF PANEL

1 1/2" TAPE MASTIC H3001

**GUTTER ANGLE LAP NOTES**


AT GUTTER ANGLE ENDS, BUTT THE PIECES  
TOGETHER, DO NOT LAP THEM.

**IMPORTANT NOTE**

AT GUTTER ENDS, HOLD THE GUTTER ANGLE FLUSH  
WITH THE END OF GHP121 TRIM.

**STEP 2**

APPLY TAPE MASTIC TO THE GUTTER ANGLE AS SHOWN. ALIGN & CLAMP THE GUTTER ANGLE TO THE ROOF PANEL. FASTEN THE GUTTER ANGLE TO THE ROOF PANEL. PLUMB THE GUTTER ANGLE AND FASTEN THE GHP121 TO THE GUTTER ANGLE.




**NOTE:** THIS STEP CAN BE COMPLETED ON THE GROUND. ALSO, HOLD THE BRACKET AT END PIECE OF GUTTER  
APPROXIMATELY 1'-0" FROM THE END OF THE GUTTER TO ALLOW ROOM FOR RAKE TRIM TRANSITION INTO THE GUTTER.

**OPTIONAL INSTALLATION**

IF DESIRED, STEPS 2 AND 3 CAN BE COMBINED  
AND DONE ON THE GROUND. IF THAT IS DONE,  
THE PANCHE HEAD FASTENER WOULD NOT  
BE REQUIRED. INSTEAD, ATTACH THE (4) H1030  
FASTENERS IN THE BACK OF THE GUTTER  
BRACKET, THROUGH THE GUTTER ANGLE. THIS  
ASSEMBLY CAN THEN BE LIFTED IN PLACE AS A  
SINGLE UNIT. THIS PROCEDURE IS MERELY  
OPTIONAL AND NOT RECOMMENDED FOR LONG  
BUILDINGS.

H3000 TAPE MASTIC CAN BE PLACED IN  
EITHER LOCATION SHOWN HERE



**STEP 3**

MARK THE LOCATIONS OF THE GUTTER BRACKETS. BASED ON THE SPACING SHOWN ABOVE LEFT. APPLY TAPE MASTIC TO THE VERTICAL BACK LEGS OF THE BRACKETS. INSTALL AN H1220 FASTENER AT THE BACK LIP OF THE GUTTER ONLY AT THIS TIME. APPLY TAPE MASTIC ALONG THE FULL LENGTH OF THE TOP OF THE BACK LIP OF THE GUTTER AS SHOWN.


**NOTE:** BE SURE TO COMPRESS THE MASTIC ALONG THE TOP.  
BACK LIP OF THE GUTTER INTO THE GUTTER ANGLE TO  
PREVENT WATER FROM WICKING BACK BEHIND THE GUTTER.

3/4" H3000 TAPE MASTIC  
BETWEEN GUTTER & GUTTER  
ANGLE

GUTTER BRACKET MK H2210  
WITH (4) H1030 FASTENERS  
AND H3000 TAPE MASTIC

**STEP 4**

LIFT THE GUTTER IN PLACE, TEMPORARILY CLAMPING IT TO THE GUTTER ANGLE. PULL THE FRONT FACE OF THE GUTTER FORWARD TO ALLOW ACCESS TO INSTALL THE (4) FASTENERS THROUGH THE BACK OF THE BRACKET & GUTTER, INTO THE GUTTER ANGLE. DO NOT YET INSTALL THE FASTENER AT THE OUTER LIP OF THE GUTTER.




**NOTE:** IF THE OPTIONAL GUTTER SUPPORT ANGLE IS  
REQUIRED IN THE DETAIL, SKIP TO STEP 6. IF IT IS NOT  
REQUIRED, CONTINUE WITH STEP 5. REFER TO THE DETAIL AT  
TOP LEFT TO DETERMINE WHETHER OR NOT IT IS REQUIRED.

(1) H1030  
FASTENER PER  
BRACKET

**STEP 5**

AFTER THE (4) FASTENERS ARE INSTALLED THROUGH THE GUTTER BRACKETS & INTO THE GUTTER ANGLE, ALONG THE ENTIRE LENGTH OF A SECTION OF GUTTER, THE FASTENER AT THE FRONT LIP OF THE GUTTER CAN BE INSTALLED. CLAMPING THE BRACKET TO THE GUTTER FACILITATES EASIER INSTALLATION.




**NOTE:** IF THE OPTIONAL GUTTER SUPPORT ANGLE IS  
REQUIRED, IT CAN BE INSTALLED AT THIS TIME. THE FASTENER  
AT THE FRONT LIP OF THE GUTTER WILL GO THROUGH THE  
GUTTER, GUTTER SUPPORT ANGLE, AND THE GUTTER  
BRACKET.

(1) H1030  
FASTENER PER  
BRACKET

**STEP 6**

AFTER THE (4) FASTENERS ARE INSTALLED THROUGH THE GUTTER BRACKETS & INTO THE GUTTER ANGLE, ALONG THE ENTIRE LENGTH OF A SECTION OF GUTTER, THE FASTENER AT THE FRONT LIP OF THE GUTTER CAN BE INSTALLED. CLAMPING THE BRACKET & GUTTER SUPPORT ANGLE BRACKET TO THE GUTTER FACILITATES EASIER INSTALLATION.



**SUPPORT ANGLE NOTES**  
AT THE END PIECES OF GUTTER, HOLD  
THE GUTTER SUPPORT ANGLE 2" FROM  
THE END OF THE GUTTER. THIS WILL  
KEEP IT OUT OF THE WAY OF THE  
GUTTER END CAP WHEN THOSE ARE  
INSTALLED (SEE CORNER DETAIL).

**ED3620**

**Detailer Notes:**

1) CLOSURES LOW EAVE LAYER DEFAULT IS ON. LAYER MUST BE TURNED OFF IF CLOSURES ARE NOT REQUIRED.