

LOW EAVE (GUTTER)

ED7001 - NBS - SCULPTURED RAKE TO ON-SLOPE GUTTER INSTALL

ED7002 - NBS - RAKE EXTENSION SPACER CAP INSTALLATION

ED7006 - NBS - LOW EAVE INSIDE CORNER GUTTER

ED7010 - NBS - HORIZONTAL GUTTER - SCULPTURED RAKE

ED7021 - LOW EAVE GUTTER TO RAKE PARAPET

ED7303 - NBS - ON-SLOPE GUTTER AT HIP

ED7304 - NBS - ON-SLOPE GUTTER AT VALLEY

ED7603 - NBS - ON-SLOPE GUTTER AT HIP

ED7604 - NBS - ON-SLOPE GUTTER AT VALLEY

ED7001 - SCULPTURED RAKE TO ON-SLOPE GUTTER INSTALL

[Download the DWG file by clicking here.](#)

STEP 1

GUTTER END CAPS

APPLY A CONTINUOUS BEAD OF **POLYURETHANE TUBE CAULK (H3152)** AROUND THREE SIDES OF THE **GUTTER END CAP (H4000_)**.

INSERT THE GUTTER CAP 1/2" (H4000_) INTO THE END OF THE GUTTER.

FASTEN WITH **POP RIVETS (H1100)** AS SHOWN IN GUTTER DETAIL. APPLY **POLYURETHANE TUBE CAULK (H3152)** AROUND PERIMETER INSIDE GUTTER TO SEAL CAP.

EXTEND GUTTER BEYOND FACE OF WALL CORNER TRIM AS SHOWN.

RAKE CAP END INSTALLATION


HOLD THE RAKE CAP END (**RSCE**) TIGHT TO THE BACK OF AND FLUSH WITH THE BOTTOM OF THE GUTTER. FASTEN TO THE WALL CORNER TRIM WITH (2) TRIM-COLORED SELF-DRILLING SCREWS (**H1050**).

RAKE CAP INSTALLATION

BEFORE INSTALLING THE RAKE TRIM, THE RAKE CAP MUST BE INSTALLED.

APPLY **POLYURETHANE TUBE CAULK (H3152)** TO (3) SIDES OF THE **RTSC** AND PLACE IT ON THE END OF THE PANEL. HOLD THE END CAP ASSEMBLY AGAINST THE CORNER TRIM TO ALIGN THE RAKE CAP TO THE BACK OF THIS ASSEMBLY. USE (3) **H1050** FASTENER FOR THE RAKE CAP. FIELD COPE FLAT OF **RTSC** AS REQUIRED TO FIT AROUND THE RAKE ANGLE.

RAKE CAP PART NUMBERS
• RTSC



RAKE CAP, GUTTER/RAKE TRIM, AND GUTTER END CAP MUST BE INSTALLED BEFORE THE RAKE TRIM.

STEP 2

RAKE TRIM INSTALLATION AT BUILDING WITH GUTTER

RAKE TRIM PART NUMBERS


- RTS_121 X 10'-1"
- RTS_242 X 20'-2"

ALL PARTS MUST BE POSITIONED PROPERLY BEFORE TOUCHING THE MASTIC TO THE ROOF PANEL. MASTIC CANNOT BE REUSED.

ALIGN THE END OF THE RAKE TRIM WITH THE END OF THE ROOF PANEL. THIS WILL LAP ONTO THE GUTTER END CAP.

ALWAYS START THE RAKE TRIM INSTALLATION AT THE LOW EAVE WORKING TOWARD THE HIGH EAVE OR RIDGE. INSTALL RAKE TRIM ACCORDING RAKE TRIM DETAIL

COPE THE BOTTOM VERTICAL LEG OF THE RAKE TRIM FLUSH WITH THE OUTSIDE EDGE OF THE WALL CORNER TRIM. FASTEN THE RAKE TRIM TO THE END CAPS USING POP RIVETS (H1100)



SCULPTURED RAKE TO ON SLOPE GUTTER

DETAIL SHOWN WITH WALL PANEL AND CORNER TRIM. MASONRY AND INSULATED WALL PANEL CONDITIONS SIMILAR.


ED7001

Detailer Notes:

1)

ED7002 - RAKE EXTENSION SPACER CAP INSTALLATION

[Download the DWG file by clicking here.](#)



RAKE EXTENSION SPACER CAP INSTALLATION



ED7002

Detailer Notes:

- 1) THIS CED IS A DUPLICATE OF DD7002.

ED7006 - LOW EAVE INSIDE CORNER TERMINATION w/ GUTTER

[Download the DWG file by clicking here.](#)



LOW EAVE INSIDE CORNER DETAIL

USE THIS DETAIL ON ALL BUILDINGS WITH SCULPTURED RAKE TRIM.
WHEN USING SCULPTURED EAVE TRIM, MITRE TO FIT RAKE TRIM.


ED7006

Detailer Notes:

- 1) THIS DETAIL IS DUPLICATE OF DD7006. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN ERECTION DRAWINGS.


ED7010 - HORIZONTAL GUTTER - SCULPTURED RAKE

[Download the DWG file by clicking here.](#)




STEP 1

- GUTTER ANGLE (GHS_121) AND GUTTER POSITIONING TRIM (GHP121) STOP FLUSH WITH FACE OF CORNER
- TRIM. EXTEND GUTTER 2" BEYOND FACE OF CORNER TRIM.
- MITER RSC TO ROOF SLOPE AND INSTALL TO FACE OF CORNER TRIM TO CLOSE OFF END OF GUTTER SUPPORT TRIMS.



STEP 2

- TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP H4000, AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO THE GUTTER. ATTACH WITH (1) H1100 RIVETS.
- APPLY POLYURETHANE CAULK AROUND THE PROFILE OF THE RSC, AND POSITION ON TOP OF GHS_121 TO FILL END OF RAKE TRIM.



STEP 3

- EXTEND RAKE TRIM TO BE IN LINE WITH END OF PANEL AND EXTEND TO BACK SIDE OF GUTTER. INSTALL RAKE CAP RSC IN END OF RAKE TRIM.
- FIELD CORN AND MITER GUTTER ANGLE (GHS_121) AND GUTTER POSITIONING TRIM (GHP121) AND RAKE TRIM BEHIND GUTTER AS NEEDED.

HORIZONTAL GUTTER TO SCULPTURED RAKE
CORNER DETAIL - HORIZONTAL GUTTER TO SCULPTURED RAKE

ED7010

Detailer Notes:

- 1) THIS DETAIL IS DUPLICATE OF DD7010. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN ERECTION DRAWINGS.

ED7021 LOW EAVE GUTTER TO RAKE PARAPET

[Download the DWG file by clicking here.](#)

RAKE PARAPET TRIM INSTALLATION

DRY FIT RAKE PARAPET CAP FOR POSITION ON PANEL. NOTCH BOTTOM OF CAP FOR RAKE ANGLE AS NEEDED. FASTEN WITH (3) **H1050** FASTENERS, (2) INTO EAVE PLATE AND (1) AT EDGE OF PANEL AS SHOWN BELOW.



APPLY 3/4" TAPE MASTIC (H3000) AROUND THE PERIMETER OF THE RAKE PARAPET CAP AS SHOWN.

PARAPET TRIM SHOULD EXTEND TO END OF ROOF PANEL AS SHOWN. INSTALL PARAPET TRIM AS INDICATED IN THE PARAPET TRIM DETAIL. ALL PARTS MUST BE POSITIONS PROPERLY BEFORE TOUCHING THE MASTIC TO ROOF PANEL AND TRIM. MASTIC CANNOT BE REUSED! PEEL PAPER OFF MASTIC ONLY AS WORK PROGRESSES.

IF YOUR BUILDING HAS A GUTTER, SEE THE GUTTER DETAIL FOR GUTTER END CAP INSTALLATION. HOLD GUTTER JUST SHORT OF EXTENDED WALL AS REQUIRED.

RAKE PARAPET CAP PART NUMBERS
• RPCL (LEFT) • RPCR (RIGHT)

RAKE PARAPET TRIM
• RPU121



NOTE: ALL POP RIVETS AND FASTENERS ARE TO BE SET "IN" THE MASTIC OR CAULK

UNIVERSAL CORNER TO PARAPET

DETAIL SHOWN WITH WALL PANEL WITHOUT GUTTER FOR CLARITY. BASIC LOW EAVE IS SHOWN. INSTALLATION OF MASONRY AND INSULATED WALL PANEL CONDITIONS SIMILAR.


ED7021

Detailer Notes:

- 1) THIS DETAIL IS DUPLICATE OF DB7021, DD7021, AND EB7021. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN ERECTION DRAWINGS.

ED7303 - NBS - ON-SLOPE GUTTER AT HIP

[Download the DWG file by clicking here.](#)



ED7303

LOW EAVE GUTTER AT HIP - LOC SEAM


ED7303

Detailer Notes:

- 1) N/A

ED7304 - NBS - ON-SLOPE GUTTER AT VALLEY

[Download the DWG file by clicking here.](#)



LOW EAVE GUTTER AT VALLEY - LOC SEAM

ED7304


ED7304

Detailer Notes:

- 1) N/A

ED7603 - NBS - ON-SLOPE GUTTER AT HIP

[Download the DWG file by clicking here.](#)



ED7603

LOW EAVE GUTTER AT HIP - CFR


ED7603

Detailer Notes:

- 1) N/A

ED7604 - NBS - ON-SLOPE GUTTER AT VALLEY

[Download the DWG file by clicking here.](#)



**SUGGESTED
GUTTER MITER**

LOW EAVE GUTTER AT VALLEY - CFR

ED7604

ED7604

Detailer Notes:

- 1) N/A