

EH6010 - HIGH EAVE STRUT w WALL PANEL

EH6030 - HIGH EAVE w MASONRY WALL

EH6050 - HIGH EAVE GIRT w NO WALL PANEL

EH6051 - HIGH EAVE STRUT w NO WALL PANEL

EH6055 - HIGH EAVE GIRT w PARTIAL WALL PANEL

EH6056 - HIGH EAVE STRUT w PARTIAL WALL PANEL

EH6610 - HIGH EAVE STRUT w INSULATED WALL PANEL




#### EH6010 - HIGH EAVE STRUT W/ WALL PANEL

Download the DWG file by clicking here.

#### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1° FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



#### Detailer Notes:

1) CLOSURES HIGH EAVE LAYER DEFAULT IS ON. LAYER MUST BE TURNED OFF IF CLOSURES ARE NOT REQUIRED.




#### EH6030 - HIGH EAVE W/ MASONRY WALL

Download the DWG file by clicking here.

#### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1° FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



#### Detailer Notes:




#### EH6050 - HIGH EAVE GIRT W/ NO WALL PANEL

#### Download the DWG file by clicking here.

#### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1° FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



#### Detailer Notes:




TRAPEZOIDAL SEAM ROOF PANELS

#### EH6051 - HIGH EAVE STRUT W/ NO WALL PANEL

#### Download the DWG file by clicking here.

#### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



#### Detailer Notes:




TRAPEZOIDAL SEAM ROOF PANELS

#### EH6055 - HIGH EAVE GIRT W/ PARTIAL WALL PANEL

#### Download the DWG file by clicking here.

#### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



#### Detailer Notes:




TRAPEZOIDAL SEAM ROOF PANELS

#### EH6056 - HIGH EAVE STRUT W/ PARTIAL WALL PANEL

#### Download the DWG file by clicking here.

#### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



#### Detailer Notes:




#### EH6610 - HIGH EAVE STRUT W/ INSULATED WALL PANEL

#### Download the DWG file by clicking here.

#### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



#### Detailer Notes:

1) THIS STANDARD DETAIL IS APPROVED FOR MIAMI-DADE USE. ALTERATIONS TO THIS DETAIL MAY IMPACT APPROVAL.

2) ANYTHING ABOVE 4" IMP WALL THICKNESS WILL REQUIRE ROOF PANEL HOLDBACK VERIFICATION.