
EXTENSIONS AND CANOPIES

SOFFIT DETAILS

- EO6005 - SOFFIT PANEL ERECTION DETAIL
- EO6006 - URBAN SERIES SOFFIT PANEL ERECTION DETAIL
- EO6007 - FLAT SL PANEL ATTACHMENT DETAIL
- EO6610 - SOFFIT PANEL ENDLAP
- EO6615 - SOFFIT PANEL - RIDGE 1:12
- EO6616 - SOFFIT PANEL - RIDGE > 1:12
- EO6617 - SOFFIT PANEL - METRO RIDGE TERM.
- EO6618 - SOFFIT PANEL - SKYLINE RIDGE TERM.
- EO6619 - SOFFIT PANEL - FLAT SL PANEL RIDGE TERM.

LOW EAVE DETAILS

- EO6700 - LOW EAVE EXT. / CANOPY W/ SOFFIT
- EO6701 - LOW EAVE EXT. / CANOPY W/O SOFFIT
- EO6710 - LOW EAVE EXT. / CANOPY W/ SOFFIT - SS360
- EO6711 - INT. LOW EAVE AT BLDG. W/O SOFFIT - SS360
- EO6712 - INT. LOW EAVE AT BLDG. W/ SOFFIT - IMP WALL PANEL - SS360
- EO6713 - LOW EAVE EXT. / CANOPY W/ SOFFIT - SS360 (EAVE PURLIN)
- EO6714 - INT. LOW EAVE AT BLDG. W/O SOFFIT - SS360 (EAVE PURLIN)
- EO6715 - INT. LOW EAVE AT BLDG. W/ SOFFIT-IMP WALL PANEL-SS360 (EAVE PURLIN)
- EO6720 - RAKE EXT. TERM. AT LOW EAVE W/ SOFFIT
- EO6721 - RAKE EXT. TERM. AT LOW EAVE W/O SOFFIT
- EO6722 - RAKE EXT. TERM. AT LOW EAVE W/ SOFFIT (EAVE PURLIN)
- EO6723 - RAKE EXT. TERM. AT LOW EAVE W/O SOFFIT (EAVE PURLIN)
- EO6724 - RAKE EXT. TERM. AT LOW EAVE W/ PERP. SOFFIT
- EO6725 - RAKE EXT. TERM. AT LOW EAVE W/ SOFFIT (EAVE PURLIN)

RAKE DETAILS

- EO6800 - RAKE TERM. AT EXT. / CANOPY W/ SOFFIT
 - EO6801 - RAKE TERM. AT EXT. / CANOPY W/O SOFFIT
 - EO6802 - RAKE EXT. W/ PERP. SOFFIT
 - EO6810 - RAKE EXT. TRIM AT ENDWALL W/ SOFFIT
 - EO6811 - RAKE EXT. TRIM AT ENDWALL W/O SOFFIT
 - EO6812 - RAKE EXT. TRIM AT ENDWALL W/ PERP. SOFFIT
 - EO6813 - RAKE EXT. TRIM AT ENDWALL W/ SOFFIT- IMP WALL PANEL
 - EO6814 - RAKE EXT. TRIM AT ENDWALL W/ PERP. SOFFIT - IMP WALL PANEL
 - EO6820 - RAKE CONT. AT EAVE EXT. W/ SOFFIT (BYPASS ENDWALL)
 - EO6821 - RAKE CONT. AT EAVE EXT. W/O SOFFIT (BYPASS ENDWALL)
-

EO6830 - RAKE CONT. AT EAVE EXT. W/ SOFFIT (INSET / FLUSH ENDWALL)
EO6831 - RAKE CONT. AT EAVE EXT. W/O SOFFIT (INSET / FLUSH ENDWALL)
EO6840 - RAKE CONT. CANOPY W/ SOFFIT (INSET / FLUSH ENDWALL)
EO6841 - RAKE CONT. AT CANOPY W/O SOFFIT (INSET / FLUSH ENDWALL)

HIGH EAVE DETAILS

EO6900 - HIGH EAVE EXT. / CANOPY W/ SOFFIT
EO6901 - HIGH EAVE EXT. / CANOPY W/O SOFFIT
EO6910 - INT. HIGH EAVE AT BLDG. W/ SOFFIT - SS360
EO6911 - INT. HIGH EAVE AT BLDG. W/O SOFFIT - SS360
EO6912 - INT. HIGH EAVE AT BLDG. W/ SOFFIT - SS360 - IMP WALL PANEL
EO6920 - RAKE EXT. TERM. - HIGH EAVE
EO6921 - RAKE EXT. TERM. - HIGH EAVE (NO SOFFIT)
EO6922 - RAKE EXT. TERM. AT HIGH EAVE W/ PERP. SOFFIT


EO6005 - SOFFIT PANEL ERECTION DETAIL

[Download the DWG file by clicking here.](#)

- H1060 STITCH FASTENER
- H1040 STRUCTURAL FASTENER

ERECTOR NOTE:

ERECTION OF THE SOFFIT PANEL MUST BE COORDINATED PROPERLY WITH THE SOFFIT TRIM CONDITIONS AS SHOWN IN THE ERECTION DETAILS. PLACEMENT AND ORIENTATION OF THE SOFFIT PANEL MAY VARY BY CONDITION AND SUPPORT MEMBERS MAY ALSO VARY. USE THIS FASTENING PATTERN UNLESS TRIM SECTION SHOWS A SPECIFIC PATTERN.



SOFFIT PANEL ERECTION DETAIL

EO6005

Detailer Notes:

1) THIS DETAIL IS A DUPLICATE OF DO0005, EO3005, HK0005 & IK0005. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN THE ERECTION DRAWINGS.


EO6006 - URBAN SERIES SOFFIT PANEL ERECTION DETAIL

[Download the DWG file by clicking here.](#)

- H1060 STITCH FASTENER
- H1040 STRUCTURAL FASTENER
- NEGATIVE LOAD CLIP (MK. NLC-1)
(SEE FLAT SL PANEL ATTACHMENT DETAIL)

ERECTOR NOTE:

ERECTION OF THE SOFFIT PANEL MUST BE COORDINATED PROPERLY WITH THE SOFFIT TRIM CONDITIONS AS SHOWN IN THE ERECTION DETAILS. PLACEMENT AND ORIENTATION OF THE SOFFIT PANEL MAY VARY BY CONDITION AND SUPPORT MEMBERS MAY ALSO VARY. USE THIS FASTENING PATTERN UNLESS TRIM SECTION SHOWS A SPECIFIC PATTERN.



**METRO, SKYLINE & FLAT SL PANEL
SOFFIT ERECTION DETAIL**


EO6006

Detailer Notes:

- 1) THIS DETAIL IS A DUPLICATE OF DO0006, EO6006, HK0006 & IK0006. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN THE ERECTION DRAWINGS.

EO6007 - FLAT SL PANEL ATTACHMENT DETAIL

[Download the DWG file by clicking here.](#)



FLAT SL PANEL ATTACHMENT DETAIL
FLAT SL PANEL ATTACHMENT AT COLD FORM SECONDARY


EO6007

Detailer Notes:

- 1) THIS DETAIL IS A DUPLICATE OF DQ0007, EO3007, EO6007, EQ3007, EQ6007, HK0007, & IK0007. DUPLICATE DETAILS ARE TO ENSURE THAT THEY ARE PLACED IN ORDER IN THE ERECTION DRAWINGS.

EO6610 - SOFFIT PANEL ENDLAP

[Download the DWG file by clicking here.](#)



SOFFIT PANEL ENDLAP

EO6610

Detailer Notes:


- 1) N/A

EO6615 - SOFFIT PANEL - RIDGE $\leq 1:12$

[Download the DWG file by clicking here.](#)

ERECTOR NOTE:

EXTEND THE PANEL PAST THE CENTERLINE OF THE RIDGE ON ONE SIDE OF THE RIDGE AS SHOWN. NEST THE OTHER PANEL INTO THE PROFILE.



SOFFIT PANEL RIDGE DETAIL

SOFFIT PANEL - SLOPES $\leq 1:12$
ALL STANDARD SOFFIT PANEL TYPES


EO6615

Detailer Notes:

- 1) N/A

EO6616 - SOFFIT PANEL - RIDGE > 1:12

[Download the DWG file by clicking here.](#)



SOFFIT PANEL RIDGE DETAIL

SOFFIT PANEL - SLOPES >1:12
ALL STANDARD SOFFIT PANEL TYPES


EO6616

Detailer Notes:

1) N/A

EO6617 - SOFFIT PANEL - METRO RIDGE TERMINATION

[Download the DWG file by clicking here.](#)



** IF PANEL SHOULD TERMINATE AT THE HIGH RIB,
ATTACH TO TRIM WITH H1100 POP RIVETS @ 1'-0" O.C.

METRO SOFFIT PANEL RIDGE DETAIL


EO6617

Detailer Notes:

1) N/A

EO6618 - SOFFIT PANEL - SKYLINE RIDGE TERMINATION

[Download the DWG file by clicking here.](#)



** IF PANEL SHOULD TERMINATE AT THE HIGH RIB,
ATTACH TO TRIM WITH H1100 POP RIVETS @ 1'-0" O.C.

SKYLINE SOFFIT PANEL RIDGE DETAIL


EO6618

Detailer Notes:

- 1) N/A

EO6619 - SOFFIT PANEL - FLAT SL PANEL RIDGE TERMINATION

[Download the DWG file by clicking here.](#)



FLAT SL PANEL SOFFIT RIDGE DETAIL

EO6619

Detailer Notes:


- 1) N/A

EO6700 - LOW EAVE EXTENSION / CANOPY WITH SOFFIT

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.




NOTE 1: PANEL RIB MUST BE SEAMED PRIOR TO INSTALLING GUTTER BRACKET!

GUTTER SHOWN IF REQ'D

☐ REQ'D ONLY FOR GUTTER

NOTE: SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

NOTE:
SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS



SOFFIT PANEL CLOSURE	
R-PANEL	COR
A-PANEL	COA
REV. R-PANEL	COV
FLAT SL. PANEL	N/A
METRO	QC-169
SKYLINE	QC-104

INSTALL LOW EAVE TRIM AND MAR26 ANGLE WITH TEMPORARY FASTENERS AT 1/3 POINTS INTO EAVE MEMBER UNTIL FINAL INSTALLATION OF SOFFIT TRIM.

LOW EAVE EXTENSION / CANOPY WITH SOFFIT

LOW EAVE WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6700

Detailer Notes:


- 1) N/A

EO6701 - LOW EAVE EXTENSION / CANOPY WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.




NOTE 1: PANEL RIB MUST BE SEAMED PRIOR TO INSTALLING GUTTER BRACKET!

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER

NOTE: SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

NOTE:
SEE ROOF PANEL BASIC INSTALLATION
DETAIL EA6013 AND EA6014 FOR
FASTENER AND SEALANT
REQUIREMENTS



LOW EAVE EXTENSION / CANOPY WITHOUT SOFFIT

LOW EAVE WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6701

Detailer Notes:

- 1) N/A

EO6710 - LOW EAVE EXTENSION / CANOPY WITH SOFFIT - SS360

[Download the DWG file by clicking here.](#)



LOW EAVE EXTENSION / CANOPY WITH SOFFIT

LOW EAVE WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6710

Detailer Notes:

- 1) N/A

EO6711 - INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT - SS360

[Download the DWG file by clicking here.](#)



INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6711

Detailer Notes:

- 1) N/A

EO6712 - INTERIOR LOW EAVE AT BUILDING WITH SOFFIT - IMP WALL PANEL - SS360

[Download the DWG file by clicking here.](#)



INTERIOR LOW EAVE AT BUILDING WITH SOFFIT - IMP WALL PANEL

EAVE WITH OR WITHOUT GUTTER DETAIL w/ SOFFIT PANELS
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6712

Detailer Notes:

- 1) N/A

EO6713 - LOW EAVE EXTENSION / CANOPY WITH SOFFIT - SS360 (EAVE PURLIN)

[Download the DWG file by clicking here.](#)



LOW EAVE EXTENSION / CANOPY WITH SOFFIT

LOW EAVE WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6713

Detailer Notes:

- 1) N/A

EO6714 - INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT - SS360 (EAVE PURLIN)

[Download the DWG file by clicking here.](#)



INTERIOR LOW EAVE AT BUILDING WITHOUT SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6714

Detailer Notes:

- 1) N/A

EO6715 - INTERIOR LOW EAVE AT BUILDING WITH SOFFIT - IMP WALL PANEL - SS360 (EAVE PURLIN)

[Download the DWG file by clicking here.](#)



INTERIOR LOW EAVE AT BUILDING WITH SOFFIT - IMP WALL PANEL

EAVE WITH OR WITHOUT GUTTER DETAIL w/ SOFFIT PANELS
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6715

Detailer Notes:


- 1) N/A

EO6720 - RAKE EXTENSION TERMINATION AT LOW EAVE WITH SOFFIT

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.




NOTE 1: PANEL RIB MUST BE SEAMED PRIOR TO INSTALLING GUTTER BRACKET!

NOTE: SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

NOTE: SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER



SOFFIT PANEL CLOSURE	
R-PANEL	COR
A-PANEL	COA
REV. R-PANEL	COV
FLAT SL PANEL	N/A
METRO	QC-169
SKYLINE	QC-104

INSTALL LOW EAVE TRIM WITH TEMPORARY FASTENERS AT 1/3 POINTS INTO EAVE MEMBER UNTIL FINAL INSTALLATION OF SOFFIT TRIM.

RAKE EXTENSION TERMINATION AT LOW EAVE WITH SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6720

Detailer Notes:


- 1) N/A

EO6721 - RAKE EXTENSION TERMINATION AT LOW EAVE WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.




NOTE 1: PANEL RIB MUST BE SEAMED PRIOR TO INSTALLING GUTTER BRACKET!

NOTE: SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

NOTE: SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER



RAKE EXTENSION TERMINATION AT LOW EAVE WITHOUT SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6721

Detailer Notes:


- 1) N/A

EO6722 - RAKE EXTENSION TERMINATION AT LOW EAVE WITH SOFFIT (EAVE PURLIN)

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.




NOTE 1: PANEL RIB MUST BE SEAMED PRIOR TO INSTALLING GUTTER BRACKET!

NOTE: SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

NOTE: SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER



RAKE EXTENSION TERMINATION AT LOW EAVE WITH SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6722

Detailer Notes:


- 1) N/A

EO6723 - RAKE EXTENSION TERMINATION AT LOW EAVE WITHOUT SOFFIT (EAVE PURLIN)

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.




NOTE 1: PANEL RIB MUST BE SEAMED PRIOR TO INSTALLING GUTTER BRACKET!

NOTE: SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

NOTE: SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER



RAKE EXTENSION TERMINATION AT LOW EAVE WITHOUT SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6723

Detailer Notes:


- 1) N/A

EO6724 - RAKE EXTENSION TERMINATION AT LOW EAVE WITH PERPENDICULAR SOFFIT

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.




NOTE 1: PANEL RIB MUST BE SEAMED PRIOR TO INSTALLING GUTTER BRACKET!

NOTE: SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

NOTE: SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER



RAKE EXTENSION TERMINATION AT LOW EAVE WITH PERPENDICULAR SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6724

Detailer Notes:


- 1) N/A

EO6725 - RAKE EXTENSION TERMINATION AT LOW EAVE WITH SOFFIT (EAVE PURLIN)

[Download the DWG file by clicking here.](#)

GUTTER LAP & END CAP

APPLY BEAD OF POLYURETHANE CAULK 1" FROM END OF TRIM AND LAP SECTIONS 2" AND FASTEN AS SHOWN. TO TERMINATE THE GUTTER APPLY POLYURETHANE CAULK TO THREE SIDES OF END CAP AND TOP RETURN AREA AS SHOWN AND INSERT 1/2" INTO END OF GUTTER. ATTACH WITH RIVETS SAME AS END LAP.




NOTE 1: PANEL RIB MUST BE SEAMED PRIOR TO INSTALLING GUTTER BRACKET!

NOTE: SEQUENCING LOW EAVE TRIM WITH WALL PANELS / OTHER TRIMS WILL BE REQUIRED.

NOTE: SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 FOR FASTENER AND SEALANT REQUIREMENTS

GUTTER SHOWN IF REQ'D

REQ'D ONLY FOR GUTTER



RAKE EXTENSION TERMINATION AT LOW EAVE WITH PERPENDICULAR SOFFIT

LOW EAVE WITH EAVE EXTENSION, AT-EAVE CANOPY, OR AT-EAVE LEAN-TO AND WITH OR WITHOUT GUTTER CONTINUATION AT RAKE EXTENSION
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6725

Detailer Notes:


- 1) N/A

EO6800 - RAKE TERMINATION AT EXTENSION / CANOPY WITH SOFFIT


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: KEEP FASTENERS 2 1/2" AWAY FROM RAKE CLIPS! REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



RAKE TERMINATION AT EXTENSION / CANOPY WITH SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6800

Detailer Notes:


- 1) N/A

EO6801 - RAKE TERMINATION AT EXTENSION / CANOPY WITHOUT SOFFIT


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: KEEP FASTENERS 2 1/2" AWAY FROM RAKE CLIPS! REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



RAKE TERMINATION AT EXTENSION / CANOPY WITHOUT SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6801

Detailer Notes:


- 1) N/A

EO6802 - RAKE EXTENSION WITH PERPENDICULAR SOFFIT


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: KEEP FASTENERS 2 1/2" AWAY FROM RAKE CLIPS! REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



SOFFIT PANEL CLOSURE	
FLAT SL PANEL	N/A
METRO	QC-169
SKYLINE	QC-104

RAKE EXTENSION WITH PERPENDICULAR SOFFIT

RAKE EXTENSION w / SOFFIT PANEL PERPENDICULAR TO WALL
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6802

Detailer Notes:

- 1) N/A

EO6810 - RAKE EXTENSION TRIM AT ENDWALL WITH SOFFIT

[Download the DWG file by clicking here.](#)



RAKE EXTENSION TRIM AT ENDWALL WITH SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS



EO6810

Detailer Notes:

- 1) N/A

EO6811 - RAKE EXTENSION TRIM AT ENDWALL WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)



PARTITION FLASHING MUST BE CUT TO LENGTH AND NOTCHED IN THE FIELD. FIELD WORK OF FLASHING WILL BE REQUIRED AT ALL PURLINS, EAVES AND RIDGES.

PARTITION TRIM CUTOUT FOR PURLINS

RAKE EXTENSION TRIM AT ENDWALL WITHOUT SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6811

Detailer Notes:

- 1) N/A

EO6812 - RAKE EXTENSION TRIM AT ENDWALL WITH PERPENDICULAR SOFFIT

[Download the DWG file by clicking here.](#)



RAKE EXTENSION TRIM AT ENDWALL WITH PERPENDICULAR SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6812

Detailer Notes:

- 1) N/A

EO6813 - RAKE EXTENSION TRIM AT ENDWALL WITH SOFFIT- IMP WALL PANEL

[Download the DWG file by clicking here.](#)



**RAKE EXTENSION TRIM AT ENDWALL
WITH SOFFIT - IMP WALL PANEL**

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6813

Detailer Notes:

- 1) N/A

EO6814 - RAKE EXTENSION TRIM AT ENDWALL WITH PERPENDICULAR SOFFIT - IMP WALL PANEL

[Download the DWG file by clicking here.](#)



RAKE EXTENSION TRIM AT ENDWALL WITH PERPENDICULAR SOFFIT - IMP WALL PANEL

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6814

Detailer Notes:


- 1) N/A

EO6820 - RAKE CONTINUATION AT EAVE EXTENSION WITH SOFFIT (BYPASS ENDWALL)

[Download the DWG file by clicking here.](#)


RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: KEEP FASTENERS 2 1/2"

AWAY FROM RAKE CLIPS!!
REFERENCE DETAIL EA6076
FOR ADDITIONAL REQUIRED
TRIM LAP FASTENER



RAKE CONTINUATION AT EAVE EXTENSION WITH SOFFIT (BYPASS ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6820

Detailer Notes:


- 1) USE THIS DETAIL WITH BYPASS OR RIGID FRAME ENDWALL CONDITIONS.

EO6821 - RAKE CONTINUATION AT EAVE EXTENSION WITHOUT SOFFIT (BYPASS ENDWALL)

[Download the DWG file by clicking here.](#)


RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: KEEP FASTENERS 2 1/2"

AWAY FROM RAKE CLIPS!!
REFERENCE DETAIL EA6076
FOR ADDITIONAL REQUIRED
TRIM LAP FASTENER



RAKE CONTINUATION AT EAVE EXTENSION WITHOUT SOFFIT (BYPASS ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6821

Detailer Notes:


- 1) USE THIS DETAIL WITH BYPASS OR RIGID FRAME ENDWALL CONDITIONS.

EO6830 - RAKE CONTINUATION AT EAVE EXTENSION WITH SOFFIT (INSET / FLUSH ENDWALL)

[Download the DWG file by clicking here.](#)


RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: KEEP FASTENERS 2 1/2"

**AWAY FROM RAKE CLIPS!
REFERENCE DETAIL EA6076
FOR ADDITIONAL REQUIRED
TRIM LAP FASTENER**



RAKE CONTINUATION AT EAVE EXTENSION WITH SOFFIT (INSET / FLUSH ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6830

Detailer Notes:


- 1) USE THIS DETAIL WITH FLUSH OR INSET ENDWALL CONDITIONS.

EO6831 - RAKE CONTINUATION AT EAVE EXTENSION WITHOUT SOFFIT (INSET / FLUSH ENDWALL)


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: KEEP FASTENERS 2 1/2" AWAY FROM RAKE CLIPS!!
REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



RAKE CONTINUATION AT EAVE EXTENSION WITHOUT SOFFIT (INSET / FLUSH ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6831

Detailer Notes:


- 1) USE THIS DETAIL WITH FLUSH OR INSET ENDWALL CONDITIONS.

EO6840 - RAKE CONTINUATION CANOPY WITH SOFFIT (INSET / FLUSH ENDWALL)


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: KEEP FASTENERS 2 1/2" AWAY FROM RAKE CLIPS!!
REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



RAKE CONTINUATION AT CANOPY WITH SOFFIT (INSET / FLUSH ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6840

Detailer Notes:


- 1) USE THIS DETAIL WITH FLUSH OR INSET ENDWALL CONDITIONS.

EO6841 - RAKE CONTINUATION AT CANOPY WITHOUT SOFFIT (INSET / FLUSH ENDWALL)


[Download the DWG file by clicking here.](#)

RAKE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION OF FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE AS SHOWN BELOW. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN. ROOF STRUCTURAL FASTENERS SHOULD BE USED TO FASTEN THROUGH PANEL FLAT INTO RAKE ANGLE.



NOTE 1: KEEP FASTENERS 2 1/2" AWAY FROM RAKE CLIPS!!
REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



RAKE CONTINUATION AT CANOPY WITHOUT SOFFIT (INSET / FLUSH ENDWALL)

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6841

Detailer Notes:


- 1) USE THIS DETAIL WITH FLUSH OR INSET ENDWALL CONDITIONS.

EO6900 - HIGH EAVE EXTENSION / CANOPY WITH SOFFIT

[Download the DWG file by clicking here.](#)



HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



NOTE 1: REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER

NOTE: SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS



SOFFIT PANEL CLOSURE	
R-PANEL	COR
A-PANEL	COA
REV. R-PANEL	COV
FLAT SL PANEL	N/A
METRO	QC-169
SKYLINE	QC-104

HIGH EAVE EXTENSION / CANOPY WITH SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6900

Detailer Notes:


- 1) EXTENSIONS BETWEEN 1'-3" AND 1'-8" - PURLIN WILL INTERFERE WITH WALL PANEL AND DETAIL WILL HAVE TO BE MODIFIED TO ADJUST WALL PANEL SET DOWN TO KEEP PURLIN AT 1'-4" FROM STEEL LINE.

EO6901 - HIGH EAVE EXTENSION / CANOPY WITHOUT SOFFIT

[Download the DWG file by clicking here.](#)


HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



NOTE 1: REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER

NOTE: SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS



HIGH EAVE EXTENSION / CANOPY WITHOUT SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6901


Detailer Notes:

- 1) EXTENSIONS BETWEEN 1'-3" AND 1'-8" - PURLIN WILL INTERFERE WITH WALL PANEL AND DETAIL WILL HAVE TO BE MODIFIED TO ADJUST WALL PANEL SET DOWN TO KEEP PURLIN AT 1'-4" FROM STEEL LINE.

EO6910 - INTERIOR HIGH EAVE AT BUILDING WITH SOFFIT - SS360

[Download the DWG file by clicking here.](#)

NOTE:
SEE ROOF INSTALLATION
DETAIL EA6013 (SIM.) AND
EA6014 FOR EAVE PLATE, AND
SEALANT REQUIREMENTS .
DO NOT INSTALL FASTENERS
(MK. H1030) THROUGH TOP OF
ROOF PANEL "PINNING ROOF".



INTERIOR HIGH EAVE AT BUILDING WITH SOFFIT

HIGH EAVE DETAIL w/ SOFFIT PANELS
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS


EO6910

Detailer Notes:

- 1) EXTENSIONS BETWEEN 1'-3" AND 1'-8" - PURLIN WILL INTERFERE WITH WALL PANEL AND DETAIL WILL HAVE TO BE MODIFIED TO ADJUST WALL PANEL SET DOWN TO KEEP PURLIN AT 1'-4" FROM STEEL LINE.

EO6911 - INTERIOR HIGH EAVE AT BUILDING WITHOUT SOFFIT - SS360

[Download the DWG file by clicking here.](#)



INTERIOR HIGH EAVE AT BUILDING WITHOUT SOFFIT

SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6911

Detailer Notes:


- 1) EXTENSIONS BETWEEN 1'-3" AND 1'-8" - PURLIN WILL INTERFERE WITH WALL PANEL AND DETAIL WILL HAVE TO BE MODIFIED TO ADJUST WALL PANEL SET DOWN TO KEEP PURLIN AT 1'-4" FROM STEEL LINE.

EO6912 - INTERIOR HIGH EAVE AT BUILDING WITH SOFFIT - SS360 - IMP WALL PANEL

[Download the DWG file by clicking here.](#)

NOTE:

SEE ROOF INSTALLATION
DETAIL EA6013 AND EA6014
(SIM.) FOR EAVE PLATE, AND
SEALANT REQUIREMENTS .
DO NOT INSTALL FASTENERS
(MK. H1030) THROUGH TOP OF
ROOF PANEL "PINNING ROOF".



**INTERIOR HIGH EAVE AT BUILDING
WITHOUT SOFFIT - IMP WALL PANEL**

HIGH EAVE WITH EAVE EXTENSION OR AT-EAVE CANOPY
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EO6912

Detailer Notes:


- 1) EXTENSIONS BETWEEN 1'-3" AND 1'-8" - PURLIN WILL INTERFERE WITH WALL PANEL AND DETAIL WILL HAVE TO BE MODIFIED TO ADJUST WALL PANEL SET DOWN TO KEEP PURLIN AT 1'-4" FROM STEEL LINE.

EO6920 - RAKE EXTENSION TERMINATION - HIGH EAVE

[Download the DWG file by clicking here.](#)


HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



NOTE 1: REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER

NOTE: SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS



RAKE EXT TERMINATION - HIGH EAVE

HIGH EAVE CONTINUATION AT RAKE EXTENSION W/ SOFFIT PANELS

EO6920

Detailer Notes:


- 1) N/A

EO6921 - RAKE EXTENSION TERMINATION - HIGH EAVE (NO SOFFIT)

[Download the DWG file by clicking here.](#)

HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER




NOTE:
SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS

OUTSIDE CLOSURE H1040 FASTENERS @ 1'-0" O.C.

SCULPTURED TRIM MK. HES

ROOF TRIM RETAINER MK. RTR121 w/ H1060 FASTENERS @ 1'-0" O.C. (BUTT TOGETHER, DO NOT LAP)

HIGH EAVE SPACER TRIM MK. HES_121



RAKE EXT TERMINATION - HIGH EAVE

HIGH EAVE CONTINUATION AT RAKE EXTENSION WITHOUT SOFFIT PANELS

EO6921

Detailer Notes:


- 1) N/A

EO6922 - RAKE EXTENSION TERMINATION AT HIGH EAVE WITH PERPENDICULAR SOFFIT

[Download the DWG file by clicking here.](#)


HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.




FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER



NOTE:
SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6013 AND EA6014 FOR FASTENER AND SEALANT REQUIREMENTS



RAKE EXTENSION TERMINATION AT HIGH EAVE WITH PERPENDICULAR SOFFIT

HIGH EAVE CONTINUATION AT RAKE EXTENSION WITHOUT SOFFIT PANELS

EO6922

Detailer Notes:

- 1) N/A