

HIP & VALLEY


EP6040 - CFR - VALLEY

EP6040 - CFR VALLEY


Download the DWG file by clicking here.

VALLEY CONDITION ERECTION NOTES


- 1) INSTALL THE EAVE ANGLES AND EAVE PLATES AS SHOWN AT RIGHT. CAULK THE EAVE PLATES AT THE CORNER WITH H1012 TUBE CAULK.
- 2) AFTER THE INSTALLATION OF THE EAVE ANGLES AND EAVE PLATES, AND BEFORE THE ROOF PANEL INSTALLATION, START AT THE LOW EAVE AND PLACE THE INSULATION PAN IN THE VALLEY AND FASTEN WITH (1) H1020 FASTENERS AT EACH PURLIN. FIELD OVER THE INSULATION PAN AT THE EAVE PLATE. LAP THE INSULATION PANS 2" AND FASTEN WITH (4) H1020 FASTENERS.
- 3) INSTALL THE INSULATION OVER THE INSULATION PAN. FASTEN WITH H1020 SCREWS AND H2000 INSULATION WASHERS AS REQUIRED.
- 4) BEFORE ROOF PANEL INSTALLATION, START AT THE LOW EAVE AND PLACE THE HAT CHANNEL SECTIONS ON BOTH SIDES OF THE VALLEY. 1" FROM THE CENTERLINE AS SHOWN. FASTEN TO EACH PURLIN WITH (2) H1020 FASTENERS.
- 5) CENTER THE VALLEY PLATE OVER THE HAT SECTIONS. AT THE EAVE & ROOGE, EXTEND THE PLATE TO THE EDGE OF THE ROOF PANEL. FIELD CUTTING AS REQUIRED. FASTEN VALLEY PLATE TO HAT CHANNEL INSIDE PANEL RIB WITH (1) H1020 FASTENER AS SHOWN BELOW. LAP THE VALLEY PLATE 2" & FASTEN WITH (2) H1020 FASTENERS.
- 6) PLACE THE DIVERTER FLASH OVER THE VALLEY PLATE AND TEMPORARILY FASTEN WITH (1) H1020 SCREW AT THE OUTSIDE CORNERS OF THE VALLEY PLATE. DO NOT USE THE VALLEY AS A WALKWAY OR A WORK PLATFORM.
- 7) INSTALL 2 1/4" TAPE MASTIC (MK H3020) ON THE DIVERTER FLASH 1/2" FROM THE CENTER OF THE PLATE AS SHOWN. DO NOT REMOVE PAPER BACKING UNTIL READY TO SET PANEL. ALSO APPLY A BEAD OF BUTYL TUBE CAULK (H3151) FOR THE FLAT OF THE PANEL ALONG THE TAPE MASTIC.
- 8) INSTALL THE ROOF PANELS - CUTTING ENDS AT THE ANGLE REQUIRED. CUT PANELS 7" FROM THE CENTER OF THE VALLEY PLATE. NOTE: KEEP METAL SHAVINGS OUT OF MASTIC AND PANEL SIDE(LAP) REMOVE TEMPORARY DIVERTER FASTENER IF NEEDED.
- 9) INSTALL THE CFR RUBBER VOID CLOSURE. REMOVE THE PAPER BACKING FROM THE 2 1/4" TAPE MASTIC AND SEAL THE VOID CLOSURE IN THE MASTIC AT THE END OF THE PANEL AND FASTEN WITH ONE H1020 SCREW. APPLY (2) PIECES OF 2 1/4" TAPE MASTIC (MK H3020), AND A BEAD OF TUBE CAULK (MK H3151) ON THE CLOSURE. SEE DETAIL BELOW.
- 10) BEFORE THE NEXT PANEL IS INSTALLED, APPLY A BEAD OF TUBE CAULK (MK H3151) TO THE MALE SIDE OF THE PANEL FROM THE LOW END OF THE PANEL UP 6" TO ENSURE WEATHERTIGHTNESS, AS SHOWN IN THE CAULK DETAIL.
- 11) FASTEN WITH H1020 SCREWS, 2 1/2" O.C. OVER THE TAPE MASTIC (MK H3020), 8 1/4" FROM THE CENTER OF THE DIVERTER FLASH TO THE CENTER OF THE FASTENERS; TAKE SPECIAL CARE AT THIS POINT TO MAINTAIN PANEL MODULARITY.




INSULATION PAN, EAVE PLATE, AND HAT CHANNEL DETAIL AT LOW EAVE CORNER
SEE ERECTION NOTES 1, 2, 3 AND 4




VALLEY PLATE AND DIVERTER FLASH DETAIL AT LOW EAVE CORNER
SEE ERECTION NOTES 5, 6 AND 7




CFR VALLEY FINAL ASSEMBLY DETAIL



ENLARGED VIEW



ROOF PANEL CUT DETAIL
SEE ERECTION NOTE 11



MASTIC AND VOID CLOSURE DETAIL AT VALLEY
SEE ERECTION NOTES 8, 9 AND 10

CFR VALLEY CONDITION
EAVE GUTTER DETAIL W/ WALL PANELS
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

EP6040

Detailer Notes:

- 1) N/A