

**HIGH EAVE (SCULPTURED)**

FH2010 - HIGH EAVE DETAIL WALL PANELS


FH2612 - HIGH EAVE DETAIL W INSULATED WALL PANELS

## FH2010 - HIGH EAVE DETAIL WALL PANELS

[Download the DWG file by clicking here.](#)


### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



**NOTE 1: REFERENCE DETAIL**  
**FA2076 FOR ADDITIONAL**  
**REQUIRED TRIM LAP FASTENER**

**NOTE:**  
SEE ROOF PANEL BASIC  
INSTALLATION DETAIL EA6011  
FOR FASTENER AND  
SEALANT REQUIREMENTS



### R-Boost™ HIGH EAVE SCULPTURED DETAIL

HIGH EAVE SCULPTURED DETAIL w/ WALL PANELS  
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

**FH2010**

### Detailer Notes:


- 1) CLOSURE LAYER IS ON BY DEFAULT.  
CLOSURE LAYER MUST BE TURNED OFF IF CLOSURES ARE NOT REQUIRED.

## FH2612 - HIGH EAVE DETAIL W/ INSULATED WALL PANELS

[Download the DWG file by clicking here.](#)

### HIGH EAVE LAP & FLASHING BACKER



SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



IMP. THICKNESS	ROOF SLOPE					
	1	2	3	4	5	6
2"	3"	3"	3"	3"	3"	3"
2.5"	3"	3"	3"	3"	3"	3"
3"	3"	3"	3"	3"	3"	3"
4"	3"	3"	3"	3"	3"	3"
5"	2"	2"	2"	2"	2"	2"
6"	1"	1"	1"	1"	1"	1"

**NOTE:**  
SEE ROOF PANEL BASIC  
INSTALLATION DETAIL EA6011  
FOR FASTENER AND  
SEALANT REQUIREMENTS  
OUTSIDE CLOSURE

**NOTE 1: REFERENCE DETAIL  
FA2076 FOR ADDITIONAL  
REQUIRED TRIM LAP FASTENER**



**R-Boost™ HIGH EAVE SCULPTURED DETAIL**  
HIGH EAVE SCULPTURED DETAIL w/ INSULATED WALL PANELS

**FH2612**

### Detailer Notes:

1) N/A