

HIGH EAVE (SCULPTURED)

FH2011-NBS - SCULPTURED HIGH EAVE W/ WALL PANEL


FH2613-NBS - SCULPTURED HIGH EAVE W/ INSULATED WALL PANEL

FH2011 - SCULPTURED HIGH EAVE W/ WALL PANEL

[Download the DWG file by clicking here.](#)

HIGH EAVE LAP & FLASHING BACKER


SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL
FA2076 FOR ADDITIONAL
REQUIRED TRIM LAP FASTENER

NOTE:
SEE ROOF PANEL BASIC
INSTALLATION DETAIL EA6013
FOR FASTENER AND
SEALANT REQUIREMENTS



R-Boost™ SCULPTURED HIGH EAVE W/ WALL PANEL

R-Boost™ ROOF SYSTEM
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

FH2011

Detailer Notes:


- 1) CLOSURES HIGH EAVE LAYER DEFAULT IS ON. LAYER MUST E TURNED OFF IF CLOSURES ARE NOT REQUIRED.

FH2613 - SCULPTURED HIGH EAVE W/ INSULATED WALL PANEL

[Download the DWG file by clicking here.](#)

HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.





FLASHING ENDLAP BACKER
FIELD CUT FROM STANDARD FEB120

NOTE 1: REFERENCE DETAIL EA6076 FOR ADDITIONAL REQUIRED TRIM LAP FASTENER

* = WALL PANEL DEPTH - 2"

NOTE:
SEE ROOF PANEL BASIC INSTALLATION DETAIL EA6011 FOR FASTENER AND SEALANT REQUIREMENTS



R-Boost™ SCULPTURED HIGH EAVE W/ INSULATED WALL PANEL

R-Boost™ ROOF SYSTEM
SEE WALL SHEETING ERECTION NOTES FOR WALL PANEL FASTENER LOCATIONS

FH2613

Detailer Notes:

- 1) N/A