

HIGH EAVE (PARAPET)

FI2010 - MASONRY WALL


FI2015 - WALL PANEL ABOVE

## FI2010 - MASONRY WALL

[Download the DWG file by clicking here.](#)


### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



**NOTE 1: REFERENCE DETAIL**  
**FA2076 FOR ADDITIONAL**  
**REQUIRED TRIM LAP FASTENER**

**NOTE:**  
REFERENCE BASIC  
INSTALLATION DETAIL EA6011 FOR  
PANEL SEALING REQUIREMENTS  
BEFORE AND AFTER CLOSURE  
INSTALLATION.



**R-Boost™ ROOF TO WALL DETAIL**  
HIGH EAVE PARAPET DETAIL WITH MASONRY WALL OR WALL BY OTHERS

FI2010

### Detailer Notes:


1) N/A

## FI2015 - WALL PANEL ABOVE

[Download the DWG file by clicking here.](#)


### HIGH EAVE LAP & FLASHING BACKER

SLIDE FIELD CUT SECTION FLASHING ENDLAP BACKER ONTO THE LOWER TRIM PIECE. PLACE TAPE MASTIC NEXT TO HEM OF THE BACKER (NOT ON TOP OF HEM). APPLY CONTINUOUS BEAD OF CAULK 1" FROM END OF TRIM DOWN PROFILE OF TRIM. FASTEN LAP WITH STITCH FASTENERS AND POP RIVETS AS SHOWN.



**NOTE 1: REFERENCE DETAIL**  
FA2076 FOR ADDITIONAL  
REQUIRED TRIM LAP FASTENER

**NOTE:**  
REFERENCE BASIC  
INSTALLATION DETAIL EA6011 FOR  
PANEL SEALING REQUIREMENTS  
BEFORE AND AFTER CLOSURE  
INSTALLATION.



### R-Boost™ ROOF TO WALL DETAIL

HIGH EAVE PARAPET DETAIL WITH WALL PANEL

FI2015

#### Detailer Notes:

1) N/A